



ULTRA AVIATION SERVICES, INC.

General Operations Manual

APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Bulletin No: 18-010

Date: 10/Oct/18

Reissued

SUBJECT: RAMP SAFETY

APPLICABLE TO: ALL RAMP PERSONNEL

Section J of ULTRA GOM J.4 details the proper ramp safety procedures when performing the arrival procedure for any flight

GSE required

Make sure that you check with operations if the arriving aircraft will need any GSE, such as GPU, AC, ASU

Have all the needed GSE at your gate ready and parked behind the equipment restraining area/line (ERA)



Personnel required

Minimum of 3 agents to meet the aircraft 1 marshaller, 2 wing walkers

Safety procedure

Do not approach the aircraft until it has come to a complete stop and the beacon has been turned off.



NOTE: If the APU is in op on the aircraft, use head set communication to communicate with the flight deck. When instructed allow the nose gear chocks to be placed, BUT DO NOT ALLOW anyone, under any circumstances, to approach or come close to the running engines to set the main gear chocks

Remember you SMS training report any unsafe acts, or hazard conditions to your supervisor or manager or anonymously to safety@ultravi.com

Be SAFE follow all ramp safety rules and company SOP

PREPARED BY:

Safety Department