



APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Bulletin No: 22-030

Date: 10/Dec/22

Reissued

SUBJECT: APPROACHING THE AIRCRAFT WITH THE BEACON "ON"

APPLICABLE TO: ALL ULTRA RAMP PERSONNEL

REMEMBER

WHEN THE AIRCRAFT BEACON LIGHT IS "ON", YOU ARE NOT ALLOWED TO APPROACH THE AIRCRAFT

Beacon location:

- 1- Under and over the fuselage mid section
- 2- under the fuselage location is between the main gears



Also remember

- 1- If the push-back tractor is connected and the pilot turns on the beacon you cannot approach the aircraft until given permission from the headset operator that is in communication with the flight deck
- 2- Once the permission is obtained then you can approach the aircraft
- 3- Do not go under the fuselage. You can hurt yourself or damage the aircraft if you impact an antenna

BE ALERT AT ALL TIMES, DO NOT BECOME AN STATISTIC

Be SAFE follow all safety rules and company SOP

PREPARED BY:

Safety Department



ULTRA AVIATION SERVICES, INC.

Bulletin No: 22-030

Date: 10/Dec/22

Reissued

SUBJECT: APPROACHING THE AIRCRAFT WITH THE BEACON "ON"

APPLICABLE TO: ALL ULTRA RAMP PERSONNEL

RECUERDA

CUANDO LA LUZ DE BALIZA DE LA AERONAVE ESTÁ "ENCENDIDA", NO SE LE PERMITE ACERCARSE A LA AERONAVE

Ubicación de la baliza:

1- Debajo y sobre la sección media del fuselaje

2- debajo del fuselaje la ubicación está entre los engranajes principales



también recuerda

1- Si el tractor push-back está conectado y el piloto enciende la baliza, no puede acercarse a la aeronave hasta que le dé permiso el operador del auricular que está en comunicación con la cabina de vuelo.

2- Una vez que se obtiene el permiso, puede acercarse a la aeronave.

3- No pasar por debajo del fuselaje. Puede lastimarse o dañar la aeronave si golpea una antena

ESTÉ ALERTA EN TODO MOMENTO, NO SE CONVIERTA EN UNA ESTADÍSTICA

Sea SEGURO siga todas las reglas de seguridad y los SOP de la compañía