



ULTRA AVIATION SERVICES, INC.

General Operations Manual

APPENDIX: 1

SAFETY & SECURITY BULLETIN (U-SMS-09)

Revision: Original

Date: 7/1/2015

Bulletin No: 20-006

Date: 2-Jul-20

Reissued

SUBJECT: BLAST FENCE

APPLICABLE TO: ALL ULTRA PERSONNEL

When operating a piece of GSE in the blast fence ramp you must remember

- 1- You can only enter thru the south side of the Blast fence Ramp area
- 2- The North side entrance has a Non- Movement/ Movement area boundary line that can not be cross without permission from the ATC FAA Tower
- 3- You cannot be inside the BLAST fence ramp area when engines are running, only qualified MTX personnel is recommended to be on head sets if applicable
- 4- If you bring an aircraft under tow. Disconnect the push tractor and the tow bar and away further instruction on the south entrance
- 5- ULTRA does not allow the use of PLB (stair truck) in this area, due to the risk of clearance to passing/ taxiing aircraft on Y and R



Be SAFE follow all safety rules and company SOP

PREPARED BY:

Safety Department