PRO SPORTS

Tracker Plus · frequently asked questions · NHL · MLB · NFL · CFL live scores · up to 12 teams

Getting started

What do I need?
Your Tracker Plus, a Wi-Fi network (2.4 GHz; it can't join 5 GHz-only networks) and a USB power supply or computer USB port.

How do I open it?
On the Home screen tap Sports, then Pro Sports. The first time, pick your teams.

How many teams can I follow?
Up to 12, in any mix of the NHL (hockey), MLB (baseball), NFL (football) and CFL (Canadian football). Tap a league at the top, then tap teams. Tap BACK when done.

Why 12?
That is the most the board's memory handles reliably while it downloads live scores securely.

Can I change my teams or time zone later?
Yes. Tap SET (top right), then My teams (tap a team to add it, again to remove it) or Time zone (tap until it matches your area).

What else is in the SET menu?
Settings (Wi-Fi, touch calibration, sound and the rest, in Home > Settings), Home (back to the Home screen), Demo and Done (back to the scores).

Is there a subscription or account?
No. Scores and weather come from free public services. Nothing to sign up for or pay monthly.

Does it remember my settings if the power goes out?
Yes. Your teams and time zone are saved. When power returns it starts at the Home screen.

Using it

Do I have to touch it?
No. It flips to the next screen on its own every 11 seconds. A live game stays up for 25 seconds.

How do I move around?
Tap anywhere on the screen to go to the next screen. Tap the league tag in the top-left corner (NHL, MLB, NFL, CFL) to jump to the next league.

What is Demo?
SET, then Demo, runs made-up games through every screen. Tap it again to go back to real scores. The Demo button on the Home screen shows all six apps.

What do @ and vs mean?
MTL @ TOR means Montreal is playing at Toronto; the team on the right is at home. In your team's list, vs means a home game and @ means an away game.

What are W3 and L2?
Streaks. A green W3 means the team has won its last 3 games, and a red L2 means it lost its last 2.

What do 2ND, BOT 7 and Q3 mean?
Where the game is. 2ND is the 2nd period (hockey), BOT 7 is the bottom of the 7th inning (baseball) and Q3 is the 3rd quarter (football).

Why are there fewer screens some days?
Screens only appear when there's something to show. A game night has live scores, pre-game countdowns and scoreboards. On an off day you'll see My Teams, Up Next, schedules and recent results.

What happens when my team wins?
The moment the game ends, the screen celebrates for 7 seconds with confetti in team colours and the final score. Tap to skip it.

Scores and data

How up to date are the scores?
During your team's game it checks every 30 seconds. Scores can run a minute or two behind TV, because the free feed updates more slowly than paid ones.

Where does the data come from?
NHL, MLB and NFL scores from ESPN (every game, preseason included), CFL from TheSportsDB, weather from Open-Meteo. All free public services.

When does it show the weather?
On the pre-game screen, for outdoor football and baseball games in the next 6 days: temperature, sky, chance of rain and wind at the stadium at start time.

Why shields instead of official team logos?
Official logos are trademarks of the leagues. Each team gets a shield in its own colours instead.

What happens in the off-season?
It counts down to the league's next opening day. If the date isn't announced yet, it shows about how many days are left.

Troubleshooting

Why does it take a while to show data? Please be patient.
Every time it opens, or when you leave the SET menu, it downloads fresh data. Give it a few seconds, and up to a minute the first time, before every screen is filled in. That's normal - it isn't stuck.

It says Loading after it opens.
That's normal for a minute or two. It downloads each team's schedule a little at a time.

It says "Score service busy - retrying shortly".
The free score service is limiting requests for a moment. It clears itself in about a minute.

The clock is off by an hour or more.
Tap SET, then Time zone, until it's right.

Taps land in the wrong place.
Go Home, then Settings > Cal and press the centre of each dot. From the Wi-Fi screen you can also hold the screen for 3 seconds.

It restarted by itself or froze.
Unplug it for 10 seconds and plug it back in. If it keeps happening, contact the seller.

Not affiliated with or endorsed by the NHL, MLB, NFL, CFL or any team. Team names are used only to identify games.