STOCK TICKER

Tracker Plus · frequently asked questions · clock · weather · stocks · crypto · news

Getting started

What do I need?
Your Tracker Plus, a Wi-Fi network (2.4 GHz; it can't join 5 GHz-only networks) and a USB power supply or computer USB port.

How do I set it up?
Nothing to set up. Tap Stock Ticker on the Home screen. Your location, time zone and weather are found automatically from your internet connection.

How do I get back to the Home screen?
Tap the top-right corner, then Home.

Is there a subscription or account?
No. Everything comes from free public services.

Using it

What does the screen show?
The time and date, today's weather with high and low, a scrolling market line (S&P 500, Dow, Nasdaq, Apple, Microsoft, Nvidia, Amazon, Google, Tesla, Bitcoin, Ethereum), world news headlines, the moon phase, how far away the space station is, and whether the New York stock market is open.

What do the green and red numbers mean?
How much each price has gone up (green) or down (red) since the last day's close.

How do I get to the settings?
Tap the top-right corner. There you can switch Celsius / Fahrenheit, refresh everything now, open Settings (Wi-Fi, touch calibration and the rest), go Home, or tap Done to go back to the dashboard.

How often does it update?
Stocks and crypto every 5 minutes, weather every 10 minutes, news every 20 minutes. The clock is always live.

Data

Where does the data come from?
Prices from Yahoo Finance and CoinGecko, weather from Open-Meteo, news from BBC World, the space station from wheretheiss.at, and your location from your internet connection. All free public services.

Are the prices real time?
Close to it, but not exactly: free price feeds can run a few minutes behind. Don't use it for trading.

Troubleshooting

Why does it take a while to show data? Please be patient.
The dashboard appears straight away and fills in as the weather, prices and news arrive in the background. It can take up to a minute before everything is there. That's normal - it isn't stuck.

The weather or time is for the wrong place.
Your location comes from your internet connection, which can point to a nearby city.

A price is missing from the market line.
The free price service didn't answer for that one. It tries again within 5 minutes by itself.

Taps land in the wrong place.
Go Home, then Settings > Cal and press the centre of each dot. From the Wi-Fi screen you can also hold the screen for 3 seconds.

It restarted by itself or froze.
Unplug it for 10 seconds and plug it back in. If it keeps happening, contact the seller.

For information only - not financial advice. Not affiliated with Yahoo, CoinGecko, BBC or any exchange.