

AIRCRAFT RADAR

Frequently asked questions · live planes around you, up to 40 nautical miles away

Getting started

What do I need?

A Wi-Fi network (2.4 GHz; the device can't join 5 GHz-only networks) and a USB power supply or computer USB port.

How do I set it up?

1) Press each of the 3 dots so the touchscreen lines up, lifting your finger between them. 2) On the setup screen, tap a field (Wi-Fi name, Wi-Fi password, Latitude, Longitude) and type on the on-screen keyboard. **NEXT** moves to the next field, **CAPS** switches capital letters, **BACK** deletes a letter. 3) Tap **SAVE**. It connects and opens the radar.

What do I type for latitude and longitude?

Your location in decimal degrees, for example 43.65 and -79.38 for Toronto. West and south are negative numbers. Tip: in Google Maps, press and hold on your home and the numbers appear at the top.

Is there a subscription or account?

No. Aircraft positions come from a free public service. There's nothing to sign up for or pay monthly.

Does it remember my settings if the power goes out?

Yes. Wi-Fi, location and touch calibration are saved. When power returns it connects by itself and goes back to the radar.

Using it

What am I looking at?

You are in the centre, with north at the top. Every plane within 40 nautical miles (about 74 km) is drawn where it is, pointing the way it is flying, with its flight number and height in feet.

How often does it update?

Every 15 seconds, by itself. You don't have to touch it.

How do I see one plane's details?

Tap **NEXT** (bottom right) to step through the planes. The bottom line shows the plane number, flight or ID, distance in nautical miles and height in feet.

Why do some planes show a code instead of a flight number?

Private planes, helicopters and some cargo flights don't send a flight number. Then it shows the plane's radio ID (a 6-character code).

How do I change my Wi-Fi or location?

Tap **SETUP** (top right), change the field, then tap **SAVE**. Tap **RADAR** to go back without changing anything.

Data

Where does the data come from?

adsb.fi, a free public network of volunteer receivers that pick up the signals planes send out.

Why are there no planes?

Either no plane is within 40 nautical miles right now (common at night or far from airports), or there is no volunteer receiver near you. The bottom line then says "No aircraft in the 40 NM area".

Troubleshooting

Why does it take a while to show data? Please be patient.

After it starts, it connects to Wi-Fi and downloads the planes around you. The first planes appear within about 15 to 30 seconds. That's normal - it isn't stuck.

It won't connect to Wi-Fi.

The line under the fields says why (for example "Wi-Fi name not found" or "Wi-Fi sign-in was refused"). Check the name and password, including capital letters, and that the network is 2.4 GHz. Move closer to the router.

It says "Radar request failed".

The free plane service didn't answer that time. It tries again every 15 seconds by itself.

It went back to the setup screen.

The Wi-Fi dropped. Tap **SAVE** to connect again; your details are still filled in.

Taps land in the wrong place.

The touch calibration is saved the first time. If it is off, contact the seller to have it reset.

It restarted by itself or froze.

Unplug it for 10 seconds and plug it back in. If it keeps happening, contact the seller.

Aircraft Radar is for fun and is not for navigation or safety. It is not affiliated with adsb.fi or any airline.