

SPORTS TRACKER

Frequently asked questions · NHL · MLB · NFL · CFL live scores

Getting started

What do I need?

A Wi-Fi network (2.4 GHz; the device can't join 5 GHz-only networks) and a USB power supply or computer USB port.

How do I set it up?

1) Tap the targets so the touchscreen lines up. 2) Pick your Wi-Fi and type the password on the on-screen keyboard. 3) Tap SET, then Time zone until it matches your area. 4) Tap SET, then My teams, and pick your teams.

How many teams can I follow?

Up to 8, in any mix of the NHL (hockey), MLB (baseball), NFL (football) and CFL (Canadian football).

Can I change my teams later?

Yes. Tap SET, then My teams. Tap a team to add it and tap it again to remove it.

Is there a subscription or account?

No. Scores and weather come from free public services. There's nothing to sign up for or pay monthly.

Does it remember my settings if the power goes out?

Yes. Wi-Fi, time zone, teams and touch calibration are all saved. When power returns it goes straight back to scores.

Using it

Do I have to touch it?

No. It flips to the next screen on its own every 11 seconds. A live game stays up for 25 seconds.

How do I move around?

Tap anywhere on the screen to go to the next screen. Tap the league tag in the top-left corner (NHL, MLB, NFL, CFL) to jump to the next league.

What is Demo mode?

SET, then Demo, runs made-up games through every screen so you can show the device off. Turn it off the same way to go back to real scores.

What do @ and vs mean?

MTL @ TOR means Montreal is playing at Toronto; the team on the right is at home. In your team's list, vs means a home game and @ means an away game.

What are W3 and L2?

Streaks. A green W3 means the team has won its last 3 games, and a red L2 means it lost its last 2.

What do 2ND, BOT 7 and Q3 mean?

Where the game is. 2ND is the 2nd period (hockey), BOT 7 is the bottom of the 7th inning (baseball) and Q3 is the 3rd quarter (football).

Why are there fewer screens some days?

Screens only appear when there's something to show. A game night has live scores, pre-game countdowns and scoreboards. On an off day you'll see My Teams, Up Next, schedules and recent results.

What happens when my team wins?

The moment the game ends, the screen celebrates for 7 seconds with confetti in team colours and the final score. Tap to skip it.

Scores and data

How up to date are the scores?

During your team's game it checks every 30 seconds. Scores can run a minute or two behind TV, because the free feed updates more slowly than paid ones.

Where does the data come from?

Scores come from TheSportsDB and weather from Open-Meteo, both free public services.

When does it show the weather?

On the pre-game screen, for outdoor football and baseball games in the next 6 days. It shows temperature, sky, chance of rain and wind at the stadium at start time. Hockey and domed stadiums don't need it.

Why no league standings or player names?

The free data doesn't include them.

Why shields instead of official team logos?

Official logos are trademarks of the leagues. Each team gets a shield in its own colours instead.

What happens in the off-season?

It counts down to the league's next opening day. If the league hasn't announced the date yet, it shows about how many days are left.

Troubleshooting

Why does it take a while to show data? Please be patient.

Every time it starts, or when you leave the SET menu, it downloads fresh scores and schedules from the internet. Give it a few seconds, and up to a minute or two after power-up, before every screen is filled in. That's normal - it isn't stuck.

It won't connect to Wi-Fi.

Check the password and that the network is 2.4 GHz. Move closer to the router. Tap SET, then Wi-Fi, to enter it again.

It says Loading after I plug it in.

That's normal for a minute or two. It downloads each team's schedule a little at a time.

It says "Score service busy - retrying shortly".

The free score service is limiting requests for a moment. It clears itself in about a minute, with nothing for you to do.

The clock is off by an hour or more.

The time zone is wrong. Tap SET, then Time zone, until it's right.

Taps land in the wrong place.

Tap SET, then Touch cal, and tap the targets again.

It restarted by itself or froze.

Unplug it for 10 seconds and plug it back in. If it keeps happening, contact the seller.

Sports Tracker is not affiliated with or endorsed by the NHL, MLB, NFL, CFL or any team. Team names are used only to identify games.