

STOCK TICKER

Frequently asked questions · clock · weather · stocks · crypto · news

Getting started

What do I need?

A Wi-Fi network (2.4 GHz; the device can't join 5 GHz-only networks) and a USB power supply or computer USB port.

How do I set it up?

1) Press each of the 3 dots so the touchscreen lines up, lifting your finger between them. 2) Pick your Wi-Fi from the list and type the password on the on-screen keyboard. 3) Tap **SAVE**. That's all: your location, time zone and weather are found automatically.

Can I set my location myself?

Yes, if the automatic one is off. In the Wi-Fi setup screen, fill in Latitude and Longitude (for example 43.65 and -79.38 for Toronto). Leave them empty to go back to automatic.

Is there a subscription or account?

No. Everything comes from free public services. There's nothing to sign up for or pay monthly.

Does it remember my settings if the power goes out?

Yes. Wi-Fi, units and touch calibration are saved. When power returns it connects by itself and goes back to the dashboard.

Using it

What does the screen show?

The time and date, today's weather with high and low, a scrolling market line (S&P 500, Dow, Nasdaq, Apple, Microsoft, Nvidia, Amazon, Google, Tesla, Bitcoin, Ethereum), world news headlines, the moon phase, how far away the space station is, and whether the New York stock market is open.

What do the green and red numbers mean?

How much each price has gone up (green) or down (red) since the last day's close.

How do I get to the settings?

Tap the top-right corner of the dashboard. There you can switch Celsius / Fahrenheit, refresh everything now, change Wi-Fi, redo the touch calibration, and go back to the dashboard.

How often does it update?

Stocks and crypto every 5 minutes, weather every 10 minutes, news every 20 minutes. The clock is always live.

Data

Where does the data come from?

Prices from Yahoo Finance and CoinGecko, weather from Open-Meteo, news from BBC World, the space station from wheretheiss.at, and your location from your internet connection. All free public services.

Are the prices real time?

Close to it, but not exactly: free price feeds can run a few minutes behind. Don't use it for trading.

Troubleshooting

Why does it take a while to show data? Please be patient.

Every time it starts, it downloads the weather, prices, news and more, one after the other. It can take up to a minute before the dashboard is filled in. That's normal - it isn't stuck.

It won't connect to Wi-Fi.

Check the password (capital letters count) and that the network is 2.4 GHz. Move closer to the router. Open settings, then Wi-Fi setup, to enter it again.

The weather or time is for the wrong place.

Your internet connection can point to a nearby city. Enter your own latitude and longitude in the Wi-Fi setup screen.

A price is missing from the market line.

The free price service didn't answer for that one. It tries again within 5 minutes by itself.

Taps land in the wrong place.

Open settings and tap Re-run touch calibration, then press each dot again.

It restarted by itself or froze.

Unplug it for 10 seconds and plug it back in. If it keeps happening, contact the seller.

For information only - not financial advice. Not affiliated with Yahoo, CoinGecko, BBC or any exchange.