HUSKY

A Peek Company

HUSKY HUNTER 16

User Guide

Husky Hunter 16

User Guide

(c) Copyright 1991 Husky Computers Limited

All Rights Reserved.

The information contained in this document is copyright and may not be reproduced, stored in a retrieval system in any form or by any means, electronic, mechanical, photocopying or otherwise without prior permission from the copyright holder, Husky Computers Limited.

Whilst every precaution has been taken in the preparation of this document, the publisher assumes no responsibility for errors and omissions neither is any liability assumed for damage resulting from the use of the information contained within this document.

Husky Computers Limited,
Eden Road
Walsgrave Triangle Business Park
Coventry CV2 2TB
England
Telephone: (0203) 604040
Facsimile: (0203) 603060

Hunter)
Hunter 16) are
Husky) trademarks
Hawk) of
8/16) Husky Computers Limited
Sidebox)
Oracle GT)

MS-DOS is a trademark of Microsoft Inc.

IBM PC and **IBM PC AT** are trademarks of IBM Corporation.

Any other trademarks used in this guide are acknowledged.

Designed, written, illustrated and set by:

Ed Phipps Documentation Services, Aldwick, Bognor Regis, England.

Second Edition (September 1991)

Contents

Chapter 1 Welcome to Husky Hunter 16 **1**
1.1 Your Hunter 16 system 2
1.2 Features 2
Chapter 2 The Hunter 16 guides **5**
Chapter 3 Using this guide **7**
3.1 Structure 7
3.2 Suggested reading approach 8
3.3 Conventions 8
Chapter 4 Introduction **11**
Chapter 5 Using Hunter 16 **13**
5.1 The Hunter 16 13
5.2 Turning on 14
5.3 Turning off 15
5.4 Rebooting 16
5.5 The screen 17
5.5.1 Introduction 17
5.5.2 Visibility 18
5.5.3 Moving around the virtual screen 19
5.5.4 Screen lookup (zoom) key 19
5.5.5 Split screen 19
5.5.6 Inverse video 21
5.6 The keyboard 23
5.6.1 Introduction 23
5.6.2 Typing keys 23
5.6.3 Special keys 25
5.6.4 International keyboards 26
5.7 Using MS- DOS 27
5.8 Using applications 29
Chapter 6 Looking after Hunter 16 **31**
6.1 Everyday Use 31
6.2 Case Sealing 31

6.3 Humidity Indicator 32
6.4 Storing Hunter 16 32
6.5 Power 33
6.5.1 Introduction 33
6.5.2 Maximising operating time 33
6.5.3 The power management system 34
6.5.4 Using non-rechargeable batteries 36
6.5.5 Using rechargeable batteries 40
6.5.6 AC Operation 46
6.6 Everyday maintenance 47
6.7 Extending, repairs and internal upgrades 47

Chapter 7 Troubleshooting 49

7.1 Avoiding Problems 49
7.1.1 Programming errors 50
7.1.2 Physical abuse 50
7.1.3 Operation Outside Specified Temperature Range 50
7.2 Diagnosing and Solving Problems 50
7.3 Checks 57
7.3.1 Communications 57
7.3.2 RTC 57
7.3.3 Files 57
7.3.4 RAM disk 58
7.3.5 Memory configuration 59

Chapter 8 The Hunter 16 System Utility 61

8.1 Introduction 61
8.2 Using the utility 61
8.3 Set time 62
8.4 Set date 63
8.5 Format diskette 63
8.6 Format fixed disk 65
8.7 Communication Port 1 Setup 67
8.8 Communication Port 2 Setup 68

Chapter 9 The HOT Key 69

9.1 Introduction 69
9.2 Status information 69
9.3 Screen option 70
9.3.1 Text font 70
9.3.2 Inverse video 71

9.3.3 Split screen 71
9.3.4 Cursor synchronisation 71
9.4 Keyboard option 71
9.4.1 Backlight timeout 72
9.4.2 Turnoff timeout 72
9.4.3 Autorepeat 72
9.5 Power option 73
9.5.1 Power remaining 73
9.5.2 Low power warning onset 73
9.5.3 Battery chargeable 74
9.5.4 Battery capacity 74
9.5.5 Charging authorisation 74

Chapter 10 The Hunter 16 Editor 75

10.1 Introduction 75
10.2 Selecting EDIT 75
10.3 File handling 75
10.4 EDIT options 76
10.5 Editing screen 77
10.6 Facilities 80
10.7 The commands 82
10.7.1 Control Keys 83
10.7.2 Function Keys 83
10.7.3 Other Keys 84
BLOCK COPY: [Ctrl][K][C] 85
BLOCK DELETE: [Ctrl][K][Y] 86
BLOCK MOVE: [Ctrl][K][V] 87
BLOCK START/END: [Ctrl][K][B], [Ctrl][K][K] 88
BLOCK WRITE: [Ctrl][K][W] 89
CHARACTER INSERT: [Ins] 90
CURSOR KEYS: [↑], [↓], [←], [→] 91
DELETE FILE: [Ctrl][K][E] 92
DELETE LEFT/RIGHT: [←], [Del] 93
DIRECTORY: [PAW][8] 94
EXIT: [PAW][2] 95
FILE START/END: [Home], [End] 96
FIND: [PAW][3] 97
LINE DELETE: [Ctrl][Y] 98
LINE START/END: [Ctrl][Q][S], [Ctrl][Q][D] 99
PAGE UP/DOWN: [PgUp], [PgDn] 100
PRINT SCREEN: [PAW][5] 101

READ FILE: [Ctrl][K][R] 102
REPLACE: [PAW][4] 103
SAVE: [PAW][1] 105
SET: [PAW][6] 106
TAB: [→|] 108
UNDELETE: [Ctrl][U] 109
VIEW FILE: [PAW][7] 110
WORD DELETE: [Ctrl][T] 111
WORD SKIP: [Ctrl][A], [Ctrl][F] 112
10.8 Error Messages 113

Chapter 11 Introduction to Communications 117

11.1 Introduction 117
11.2 Communications packages 119
11.3 Background information 119
11.3.1 Buffering 120
11.3.2 Data Transmission 120
11.3.3 Data Reception 121
11.4 Connecting up 121
11.4.1 Main port (COM1) 121
11.4.2 Auxiliary port (COM2) 122
11.4.3 Pinouts 122
11.5 Configuring Husky communications 124
11.5.1 Handshaking 125
11.5.2 Protocols 126
11.5.3 Port set-up options 129
11.6 Configuring IBM communications 137
11.7 Example communications set-up 138
11.7.1 Another Hunter 16 138
11.7.2 Husky Hunter 139
11.7.3 Husky Hawk and Hawk 8/16 140
11.7.4 External modem 140
11.7.5 IBM personal computers 141
11.7.6 Serial printer 143

Chapter 12 Using Communications 147

12.1 Introduction 147
12.2 Selecting the communications package 147
12.3 Starting communication 148
12.4 Using standard facilities 149

12.5 Using the COM utility 150
12.5.1 Setting up 150
12.5.2 Command options 150
12.5.3 Sending a file 151
12.5.4 Receiving a file 151
12.5.5 Examples 151
12.6 Using Hunter 16 applications 152
12.6.1 Writing communications programs 152
12.7 Using MS-DOS applications 152
12.8 Using MS-DOS communications packages 153
12.9 Example file transfer 153
12.9.1 Exchanging files with another Hunter 16 154
12.9.2 Exchanging files with Husky Hunter/Hawk 155
12.9.3 Exchanging files with Husky Hawk 8/16 157
12.9.4 Using Intel Hex format 159
12.10 Troubleshooting 159
12.10.1 Error messages 160

Chapter 13 Hunter 16 Accessories 163

13.1 Introduction 163
13.2 Power 163
13.3 Oracle GT drive 164
13.4 Extra Memory 165
13.4.1 RAM 165
13.4.2 User EPROM 165
13.5 Hunter 16 Printer Sidebox 165
13.6 Communications 166
13.6.1 Protocols 166
13.6.2 Communications expansion module 166
13.7 Bar codes 166

Chapter 14 Introduction 167

14.1 Using this part of the guide 167
14.2 Assumptions 167
14.3 Conventions 167

Chapter 15 Installing standard applications 169

15.1 Compatibility 169
15.2 Porting the application 170
15.3 Configuring 171
15.4 Testing 173

15.5 Hunter 16 operating system and utilities 173
15.6 Special considerations 174
15.6.1 Batteries 174
1S.6.2 Display 175
15.6.3 Training 176

Chapter 16 Adapting applications 177

16.1 Using PC-DOS or MS-DOS software 177
16.2 Using BASIC software 178
16.3 Using Husky Hawk 8/16 software 179

Chapter 17 Programming 181

17.1 Introduction 181
17.2 Tools 181
17.3 Compatibility 181
17.4 Extra facilities 182

Chapter 18 Hunter 16 Interrupts 183

18.1 The interrupts 183
18.2 BIOS interrupts 186

Chapter 19 INT 05H, Print screen contents 189

Chapter 20 INT 10H, Screen handler 191

Set screen mode 194
Set cursor size 194
Move cursor 195
Get cursor position 195
Get cursor address 195
Set display page 196
Scroll up 196
Scroll down 196
Read character and attributes 197
Write character plus attributes 197
Write character 198
Write pixel 198
Read pixel 198
Write character as TTY 199
Get video state 199
Write string 199
Set graphics font 200
Move cursor to graphics co-ordinates 201

Get cursor position in graphics co-ordinates 201
Set contrast 202
Set backlight level 202
Get/set backlight timeout 202
Split display 203
Draw ellipse/circle 203
Draw line/box 204
Select inverse video mechanism 205
Select text font 206
Set LCD window position 207
Zoom 208
Looking keys 208
Get graphics font 208
Turn backlight on/off 209

Chapter 21 INT 11H, Check system equipment 211

Chapter 22 INT 12H, Check memory size 213

Chapter 23 INT 13H, Disk handler 215

Reset disks 217
Read disk status 217
Read sectors 217
Write sectors 218
Verify sectors 218
Format track 219
Read current drive parameters 220
Get disk type 220
Change diskette status 221
Set media type 221

Chapter 24 INT 14H, Serial port handler 223

Initialise port 225
Send character 226
Input character 226
Check status 226
Extended initialise port 227
Read comms parameters 228
Select comms parameters 231
Extended control 235
Extended status 235
Control handshake lines 236

Control CTS 236
Control RS232 drivers 236
Control RI power up 237
Get installed protocols count 238
Get protocol name 238
Get protocol handle 238
Extended protocol menu 239
Get extended protocol parameters 239
Get/set DTR 239

Chapter 25 INT 15H, BIOS extension functions 241

Set clock speed 244
Get power level (APM) 244
Set low power threshold (APM) 244
Get/set idle timeout 245
Control Resume mode 245
Authorise charging (APM) 246
Set battery level (APM) 248
Control STOP mode 248
Power down 249
Control power down 249
Control SLOW mode 250
Get ROM BIOS version number 250
Get serial number 250
Get event details 251
Enable/trap event 251
Acknowledge event 253
Control sound 253
Power up keys 253
Redirect serial number 255
Get Oracle GT power level 255
Set backlight power up state 256
Set contrast power up state 256
Control power save 256
Redirect LPT 257
Invoke HOT key 257
Control HOT key 258
Control HOT key power option 258
Override low power turn off 259
Control battery change facilities (APM) 259
Set battery type (APM) 260

Set battery capacity (APM) 261
Control power output 261
Sound output 262
Control screen synchronisation 263
Get/set diskette port 263
Set/restore power menu (APM) 264
Get/set screen attribute table 264
Set INT 72H vector 265
Get power up keys 266
Get/set power mode 266
Control power input (SPM) 267
Set charger temperature override 267
Get/set power save entry flag 268
Get/set boost charge (SPM) 268

Chapter 26 INT 16H, Keyboard handler 271

Get key 272
Get status 272
Get shift status 272
Set key repeat 273
Write to buffer 274
Extended get key 274
Extended get status 274
Extended get shift status 274
Set temporary shift 275
Control shift keys 276
Control [Ctrl][Alt][Del] 276
Control emergency breakout 277
Redefine key codes 278
Reset keyboard 279
Control keyclick 280
Control screen dump area 280
Get key repeat 280
Control key repeat 281
Redefine key scan codes 281
Redefine PAW key codes 282
Control Break keys 283

Chapter 27 INT 17H, Printer control 285

Print byte 286
Initialise printer 286
Get printer status 286

Chapter 28 INT 19H, Reboot **287**

Chapter 29 INT 1AH, Clock handler **289**

Get system clock 290
Set system clock 290
Get RTC time 290
Set RTC time 291
Get RTC date 291
Set RTC date 292
Set RTC alarm 292
Disable RTC alarm 292
Get RTC alarm time 293

Chapter 30 INT 67H, Expanded memory **295**

Get status 296
Get page frame address 296
Get unallocated page count 296
Allocate pages 297
Map handle to page 297
De-allocate pages 297
Get EMM version 297
Save page map 298
Restore page map 298
Get page map register array 298
Get logical-to-physical array 299
Get EMM handle count 299
Get EMM pages allocated to handle 299
Get all pages and handles 299
Get/set page map 300

Chapter 31 INT 71H, Barcode input **301**

Chapter 32 Hardware **303**

32.1 Organisation 303
32.2 Memory maps 304
32.2.1 Logical memory map 305
32.2.2 Physical memory map 306
32.2.3 I/Ó addresses 306
32.3 Hardware interrupts 310
32.4 Device details 311
32.4.1 CGA and 6845 emulation (display) 312
32.4.2 825S emulation (various) 315
32.4.3 8253 emulation (timers) 317

32.4.4 8250 emulation (serial) 319
32.4.5 Parallel printer port 325
32.4.6 8237 emulation (DMA controller) 325
32.4.7 8259 emulation (Interrupt controller) 326
32.4.8 Disk controllers 329

Chapter 33 Using the subsystems 331

Chapter 34 Using the display 333

34.1 Standard facilities 333
34.1.1 BIOS 333
34.1.2 Character sets 334
34.1.3 RAM 334
34.1.4 Hardware 334
34.2 Extra facilities 335
34.2.1 BIOS 335
34.2.2 Character sets 336
34.2.3 Control keys 336
34.3 Using the extra facilities 336
34.3.1 Graphics facilities 336
34.3.2 Scrolling 341
34.3.3 Windowing 342
34.3.4 Using inverse video 343
34.3.5 Using the controls 344

Chapter 35 Using the keyboard 345

35.1 Standard facilities 345
35.1.1 Keyboard layout 345
35.1.2 BIOS 345
35.1.3 Interrupts 345
35.1.4 RAM 346
35.2 Extra facilities 347
35.2.1 Extra keys 347
35.2.2 BIOS 347
35.3 Using the extra facilities 348
35.3.1 Redefining keys 348
35.3.2 Protecting an application 349
35.3.3 Initialising the keyboard 350
35.3.4 Simulating keyboard input 351

Chapter 36 Using the hard disks **353**
36.1 Standard facilities 353
36.1.1 BIOS 353
36.1.2 Structure 353
36.2 Extra facilities 354
36.2.1 Physical structure 354
36.2.2 BIÒS functions 355
36.2.3 Data integrity 355
Chapter 37 Using diskettes **357**
37.1 Standard facilities 357
37.1.1 BIOS 357
37.1.2 Disk base table 357
37.1.3 Diskette format 358
37.2 Extra facilities 358
37.2.1 Formatting 358
37.2.2 Booting 359
37.2.3 BIOS 359
37.2.4 Low level access 359
37.2.5 Use with a desktop computer 359
Chapter 38 Using communications **361**
38.1 Standard facilities 361
38.1.1 BIOS 361
38.1.2 Interrupts 362
38.1.3 RAM 362
38.1.4 Hardware 362
38.2 Extra facilities 362
38.2.1 BIOS 362
38.2.2 Husky communications 363
48.2.3 Configuration menu 364
38.2.4 Interface power 364
38.3 Using the extra facilities 364
38.3.1 Transmitting a file 364
38.3.2 Receiving a file 366
38.3.3 Using an autoanswer modem 368
Chapter 39 Using printers **371**
39.1 Standard facilities 371
39.1.1 BIOS 371
39.1.2 Hardware 371

39.2 Extra facilities 372

Chapter 40 Using power handling 373

40.1 The facilities 373
40.1.1 Power-up 373
40.1.2 Power-down 375
40.1.3 Power monitoring and charging 377
40.1.4 Saving power 380
40.1.5 Power output 382
40.2 Using the facilities 382
40.2.1 Setting up 382
40.2.2 Using SLOW mode 384
40.2.3 Charging NiCad batteries 385

Chapter 41 Using events 391

41.1 The facilities 391
41.2 Using the facilities 392

Chapter 42 Using EMS memory 393

42.1 The facilities 393
42.2 Using the facilities 394

Appendix A Specification 399

A.1 Physical 399
A.2 Fascia 399
A.3 Programming 400
A.4 Communications 401
A.5 Screen 402
A.6 Memory 402
A.7 Clock/calendar 403
A.8 Microprocessor 403
A.9 Batteries 403

Appendix B Operating Environment 405

B.1 Operating Temperature 405
B.2 Humidity 405
B.3 Waterproofing and Dustproofing 405
B.4 Storage Conditions 406
B.5 Electromagnetic Compatibility 406
B.6 Resistance to Shock, Vibration and Impact 407

Appendix C Character Sets **409**
C.1 Character set 8 x 6 pixels 409
C.2 Character set 8 x 8 pixels 414
C.3 Character set 9 x 7 pixels 420
C.4 Character set 6 x 4 pixels 425

Appendix D Hexadecimal to Decimal Conversion **429**

Appendix E Keyboards **431**
E.1 Keyboard layouts 431
E.2 Key matrix codes 434
E.3 Scan codes 435

Appendix F Interfacing **441**
F.1 25-way D type (COM1) 441
F.2 5-way FISCHER (COM2) 443
F.3 4-way LEMO 444