**Note:** This tutorial assumes that you have completed the previous tutorials: ROS tutorials (/ROS/Tutorials).

Fig. Please ask about problems and questions regarding this tutorial on ●answers.ros.org (http://answers.ros.org). Don't forget to include in your question the link to this page, the versions of your OS & ROS, and also add appropriate tags.

# Sending Goals to the Navigation Stack

**Description:** The Navigation Stack serves to drive a mobile base from one location to another while safely avoiding obstacles. Often, the robot is tasked to move to a goal location using a pre-existing tool such as rviz in conjunction with a map. For example, to tell the robot to go to a particular office, a user could click on the location of the office in a map and the robot would attempt to go there. However, it is also important to be able to send the robot goals to move to a particular location using code, much like rviz does under the hood. For example, code to plug the robot in might first detect the outlet, then tell the robot to drive to a location a foot away from the wall, and then attempt to insert the plug into the outlet using the arm. The goal of this tutorial is to provide an example of sending the navigation stack a simple goal from user code.

**Tutorial Level: BEGINNER** 

#### Contents

- 1. Pre-Requisites
- 2. Some ROS Setup
- 3. Creating the Node
- 4. Building and Running
- 5. Learning more about map navigation

catkin

rosbuild

## 1. Pre-Requisites

This tutorial assumes basic knowledge of how to bring up and configure the navigation stack. This may be different depending on the platform that you're running on. Below is a list of tutorials for known platforms at the time of this writing. Please feel free to update it as more tutorials for different robots become available.

- Running the navigation stack on the PR2 platform (/pr2\_2dnav)
- Simulating the 2dnav Stack (/pr2\_2dnav\_gazebo/Tutorials/Simulating%20the%202dnav%20Stack)

### 2. Some ROS Setup

In order to create a ROS node that sends goals to the navigation stack, the first thing we'll need to do is create a package. To do this we'll use the handy command where we want to create the package directory with a dependency on the move base msgs, actionlib, and roscpp packages as shown below:

\$ catkin\_create\_pkg simple\_navigation\_goals move\_base\_msgs actionlib roscpp

After this is done we'll need to roscd to the package we created, since we'll be using it as our workspace

roscd simple\_navigation\_goals

Toggle line numbers

## 3. Creating the Node

Now that we have our package, we need to write the code that will send goals to the base. Fire up a text editor and paste the following into a file called **src/simple\_navigation\_goals.cpp**. Don't worry if there are things you don't understand, we'll walk through the details of this file line-by-line shortly.

```
1 #include <ros/ros.h>
   2 #include <move_base_msgs/MoveBaseAction.h>
   3 #include <actionlib/client/simple_action_client.h>
   5 typedef actionlib::SimpleActionClientmove_base_msqs::MoveBaseActior
Mov
eBaseClient;
   6
   7 int main(int argc, char** argv){
       ros::init(argc, argv, "simple_navigation_goals");
  10
       //tell the action client that we want to spin a thread by default
       MoveBaseClient ac("move_base", true);
  11
  12
       //wait for the action server to come up
  13
  14
       while(!ac.waitForServer(ros::Duration(5.0))){
         ROS_INFO("Waiting for the move_base action server to come ub);
  15
  16
       }
  17
  18
       move_base_msgs::MoveBaseGoal goal;
  19
  20
       //we'll send a goal to the robot to move 1 meter forward
  21
       goal.target_pose.header.frame_id = "base_link";
  22
       goal.target_pose.header.stamp = ros::Time::now();
  23
  24
       goal.target_pose.pose.position.x = 1.0;
  25
       goal.target_pose.pose.orientation.w = 1.0;
  26
  27
       ROS_INFO("Sending goal");
       ac.sendGoal(goal);
  28
  29
  30
       ac.waitForResult();
  31
  32
       if(ac.getState() == actionlib::SimpleClientGoalState:SUCCEEDED)
  33
         ROS_INFO("Hooray, the base moved 1 meter forward);
  34
       else
  35
         ROS_INFO("The base failed to move forward 1 meter for some reasoh);
  36
  37
       return 0;
  38 }
```

Now, we'll break the code down line by line:

```
Toggle line numbers

2 #include <move_base_msgs/MoveBaseAction.h>
3
```

This line includes the action specification for move\_base which is a ROS action that exposes a high level interface to the navigation stack. Essentially, the move\_base action accepts goals from clients and attempts to move the robot to the specified position/orientation in the world. For a detailed discussion of

ROS actions see the actionlib documentation (/actionlib).

```
Toggle line numbers

5 typedef actionlib::SimpleActionClient<move_base_msgs::MoveBaseActior> MoveBaseClient;
```

This line creates a convenience typedef for a SimpleActionClient that will allow us to communicate with actions that adhere to the MoveBaseAction action interface.

```
Toggle line numbers

10 //tell the action client that we want to spin a thread by default
11 MoveBaseClient ac("move_base", true);
```

This line constructs an action client that we'll use to communicate with the action named "move\_base" that adheres to the MoveBaseAction interface. It also tells the action client to start a thread to call ros::spin() so that ROS callbacks will be processed by passing "true" as the second argument of the MoveBaseClient constructor.

```
Toggle line numbers

13 //wait for the action server to come up
14 while(!ac.waitForServer(ros::Duration(5.0))){
15 ROS_INFO("Waiting for the move_base action server to come ub);
16 }
```

These lines wait for the action server to report that it has come up and is ready to begin processing goals.

```
Toggle line numbers
  18
       move_base_msgs::MoveBaseGoal goal;
  19
  20
       //we'll send a goal to the robot to move 1 meter forward
       goal.target pose.header.frame id = "base link";
  21
  22
       goal.target_pose.header.stamp = ros::Time::now();
  23
  24
       goal.target_pose.pose.position.x = 1.0;
  25
       goal.target_pose.pose.orientation.w = 1.0;
  26
  27
       ROS_INFO("Sending goal");
  28
       ac.sendGoal(goal);
```

Here we create a goal to send to move\_base using the move\_base\_msgs::MoveBaseGoal message type which is included automatically with the MoveBaseAction.h header. We'll just tell the base to move 1 meter forward in the "base\_link" coordinate frame. The call to ac.sendGoal will actually push the goal out over the wire to the move\_base node for processing.

```
Toggle line numbers
```

```
ac.waitForResult();
31

if(ac.getState() == actionlib::SimpleClientGoalState:SUCCEEDED)
ROS_INFO("Hooray, the base moved 1 meter forward);
else
ROS_INFO("The base failed to move forward 1 meter for some reaso"h);
```

The only thing left to do now is to wait for the goal to finish using the ac.waitForGoalToFinish call which will block until the move\_base action is done processing the goal we sent it. After it finishes, we can check if the goal succeeded or failed and output a message to the user accordingly.

## 4. Building and Running

Now that we have a package and a source file, we'll want to build and then try things out. The first step will be to add our src/simple\_navigation\_goals.cpp file to our CMakeLists.txt file to get it to build. Open up CMakeLists.txt in your editor of choice and add the following line to the bottom of the file.

```
add_executable(simple_navigation_goals src/simple_navigation_goals.cpp)
target_link_libraries(simple_navigation_goals ${catkin_LIBRARIES})
```

Once this is done, we can build our executable by typing make.

```
$ catkin_make
```

Now we're ready to run. At this point, we'll assume that the navigation stack has been brought up according to one of the tutorials listed above (/navigation/Tutorials/SendingSimpleGoals#Pre-Requisites). One important thing to check is that the name of the action, we've assumed "move\_base" in this tutorial, matches the name used in your code. To check this, we'll execute the following rostopic command:

```
rostopic list | grep move_base/goal
```

If something shows up, then you're good to go. Otherwise, you need to find the name of the action that the navigation stack is using, a common alternative on the PR2 platform is "move\_base\_local," and update all references in the src/simple navigation goals.cpp file accordingly.

After this, its as simple as running the executable we created.

```
./bin/simple_navigation_goals
```

And, if all goes well, the robot should begin to move a meter forward.

## 5. Learning more about map navigation

You can learn more about map navigation through • Gaitech EDU (http://edu.gaitech.hk/) tutorial on • Map Navigation (http://edu.gaitech.hk/turtlebot/map-navigation.html)

Except where otherwise

noted, the ROS wiki is Wiki: navigation/Tutorials/SendingSimpleGoals (last edited 2016-08-25 10:01:05 by AnisKoubaa (/AnisKoubaa)) licensed under the

Creative Commons Attribution 3.0 (http://creativecommons.org/licenses/by/3.0/) | Find us on Google+ (https://plus.google.com/113789706402978299308)

Brought to you by: Open Source Robotics Foundation

(http://www.osrfoundation.org)