FUNC: Thrust and Power Required for Executive Jet Example

>>Details

- (1) Description: This program uses predefined equations with provided coefficients to calculate the thrust for a certain executive jet.
- (2) Input values:
 - 1. vel: free stream velocity [m/s] or [ft/s]
- (3) Output values:
 - thrust: thrust [N]
 power: power [W]

```
function [thrust, power] = ExecJet_thrustPower_cal(vel)
% Preparations
mass = 33100; % Mass of the aircraft [kg]
wing area = 88.2; % Wing surface area [m^3]
grav = 9.81; % Gravitational acceleration [m/s^2]
rho = 1.225; % Air density at sea level [kg/m^3]
C D0 = 0.015; % Zero lift drag coefficient
K = 0.05; % Drag polar coefficient
% Calculate
% First calculate lift coefficient
C_L = 2 * mass * grav / rho ./ vel.^2 ./ wing_area;
% Then calculate the drag coefficient with drag polar
C_D = C_{D0} + K * C_L.^2;
% Thrust is approximated to be equal to drag
thrust = 0.5 * rho .* vel.^2 * wing_area .* C_D;
% Than power is the product of thrust and velocity
power = thrust .* vel;
end
```