ELG v0.4 | Axial draw scale

PRINT AT 100% / ACTUAL SIZE. Disable Fit to page. Check the 100 mm bar below.
Readout = distance along ruler from hook station to anchor-pin center (mm).
This is not the rubber path length. Pullback extension = loaded reading - relaxed reading.
Attach to the SIDE with segment 1 start at the wooden ruler front end. Values grow rearward.
Overlap successive strips by 10 mm using matching ticks; trim only after checking alignment.

Segment 1: 0 to 200 mm behind front end | readout 15 to 215

FRONT END: readout starts at 15 mm; the pin center is 15 mm beyond the wood.

Segment 2: 190 to 390 mm behind front end | readout 205 to 405

Segment 3: 380 to 580 mm behind front end | readout 395 to 595

Segment 4: 570 to 770 mm behind front end | readout 585 to 785



Segment 5: 760 to 914.4 mm behind front end | readout 775 to 929.4



Size check: the line below must measure exactly 100 mm.



Default wood length: 914.4 mm. The scale is specific to this anchor geometry.
Align marker center with the selected readout. Keep tape and paper below the top plane.
Ruler axes: rear x = 0, front x = L; hook station = xH; axial reading D = L + 15 - xH.
For actual straight endpoint distance include measured vertical and lateral offsets.
Do not infer elastic force from length; record the rubber ID, relaxed zero and measured load separately.