



ZT368T-G

Maintenance Manual



2025-01-07

Preface

All the information, illustrations, photos, etc. collected in this manual are compiled based on the latest product of ZT368T-G low pedal low seat version of National IV . However, due to the continuous improvement of products and other changes, your motorcycle may be inconsistent with this manual. For color or upgrade, please refer to the part code of ZONTES official website. This manual will not list it in detail; if the part name in this manual is inconsistent with ZONTES official website, ZONTES official website shall prevail.

If some of the contents of this manual are insufficient, please refer to the " Driving Manual" that comes with the vehicle. The latest version of the driving manual can be downloaded in PDF format in the corresponding model introduction on the ZONTES official website.



© Guangdong Tayo Motorcycle Technology Co., Ltd.
all rights reserved

User Notice

This manual is compiled by Guangdong Tayo Motorcycle Technology Co., Ltd. for the guidance of dealers or service personnel . This manual cannot provide more detailed knowledge about motorcycles and is only used as a maintenance reference. If you do not have the corresponding knowledge such as electrician and mechanic, improper assembly or maintenance failure may occur during repair .

If you need to clean or wash the body parts of this vehicle, you should use neutral motorcycle wash liquid or tap water or diesel, kerosene, etc. Acidic or alkaline motorcycle wash liquids will cause irreversible corrosion to the paint, electroplated surface, anodized surface, etc. on the surface of the parts ; gasoline will cause premature aging or hardening of sealants, gaskets , rubber parts, etc., reducing the service life . Use non-woven cloth without residue for wiping. Ordinary rags may have cloth scraps or wool left on them , affecting assembly or causing other adverse effects.

Our company will try its best to update this manual in a timely manner after any changes are made to the product .

The following are the meanings of the icons in this manual:

 DANGER	Failure to comply may result in personal injury or death of the driver or maintenance personnel ; or cause serious damage to spare parts , shortening of service life, etc.
 WARNING	Failure to comply may result in personal injury or death to the driver or maintenance personnel ; or may result in damage to spare parts , abnormality, etc.
 CAUTION	Failure to comply with warnings may result in personal injury to the driver or maintenance personnel ; or matters requiring special attention during disassembly and assembly
	Indicates that there is a torque requirement at this location
	Indicates that the part needs to be replaced after disassembly
	To facilitate electronic reading, if there is a symbol on the right side of the step, you can click the symbol to quickly jump to the corresponding chapter

Contents

Preface	2
User Notice	3
Contents	4
1. Vehicle Information	9
Notice before service.....	9
Motocycle body stickers	10
368G Technical Parameters.....	11
Front wheel/steering system	11
Rear wheel/suspension system	11
Braking system.....	12
Battery/Charging System	12
Lighting/Instrument/Switch Description.....	12
Tightening torque	13
Bolt tightening torque for general fastening parts.....	13
Cable/pipeline/electrical components distribution diagram.....	14
1. Lighting distribution map	14
2. Throttle cable.....	14
3. Brake pump and brake oil pipe	15
4. Calipers, brake hoses and wheel speed sensors	15
5. Braking system parts distribution diagram	16
6. Oil supply system	17
6.1 Fuel evaporation.....	17
6.2 Fuel supply	18
7. Cooling system accessories distribution diagram.....	19
8. Electrical device layout diagram.....	19
9. Intake and exhaust system.....	21
Tool.....	22
Expansion nail description	24
2. Maintenance	25
Notice before service.....	25
Maintenance cycle table	26
Air filter (filter element) , air inlet filter element.....	27
1. Support the vehicle firmly	27
2. Remove the left engine cover.....	27
3. Replace the air inlet filter	27
4. Remove the air filter housing.....	28
5. Replace the air filter element	28
6. Check the air filter waste oil pipe.....	28
7. Reinstallation	28
Muffler bolts and nuts	29
Engine oil	30
1. Drain the engine oil	30
2. Replace the fine filter	30
3. Add engine oil	31
4. Replace gearbox oil	31
5. Confirm the oil level	31
Throttle body	32
1. Clean carbon deposits without removing the throttle valve body.....	32
2. Remove the stepper motor and clean the carbon deposits.....	32
3. Remove the throttle valve body assembly and clean the carbon deposits.....	32
4. Remove the sensor from the throttle valve body	33
5. Throttle valve body troubleshooting process	34
Throttle cable	34
1. Inspection	34
2. Adjust the throttle cable clearance	34
Idle -Done	35

Check the idle speed	35
Fuel Evaporative Pollutant Control System	36
Heat sink	37
1. Check the coolant	37
2. Add coolant (antifreeze) to the auxiliary water tank.....	37
3. Add coolant to the main water tank.....	37
4. Release coolant.....	38
5. Check whether the fins of the radiator tank are deformed or the air duct is blocked	38
6. Check all water pipes for leakage and aging	39
Brake hose.....	40
Brake fluid	40
1. Add brake fluid to the front and rear disc brake master cylinders.....	40
2. Replace brake fluid.....	40
2.1 Replace the front brake fluid.....	40
2.2 Replace rear brake fluid	41
3. Exhaust of brake system	41
Tire	41
1. Check the tires	42
2. Replace tires	42
Front fork	42
1. Check the appearance	43
2. Check shock absorption performance.....	43
3. Disassemble the front shock absorber	43
4. Correct the front fork tube	43
5. Troubleshooting.....	44
Side Bracket - Complete.....	44
1. Inspection.....	44
2. Lubrication.....	44
Main bracket	45
1. Inspection.....	45
2. Lubrication.....	45
3. Install the main bracket	46
4. Replace the main bracket reset spring column	46
Sound, light and electrical device inspection	46
1. Inspection	46
Charging method.....	47
2. Headlight height adjustment	47
3. Fuse box	48
4. Troubleshooting	49
4.1 Right-hand switch	49
4.2 Right-hand handle auxiliary switch.....	49
4.3 Left handlebar switch	50
4.4 Speakers.....	50
4.5 Left handle switch.....	51
4.6 Lamps.....	52
3. Electronic fuel injection system	53
Notice before service.....	53
Fault Codes.....	54
1. Read the fault code through the instrument	54
2. Read the fault code through the diagnostic instrument.....	54
3. Clear fault codes	55
3.1 Manual Removal.....	55
3.2 Clear using diagnostic instrument	55
EFI parts layout.....	56
Fault diagnosis and troubleshooting of EFI parts	57
1. EFI relay	57
2. Crankshaft position sensor	57
3. Throttle valve body	57
3.1 Common fault phenomena	57
3.2 Sensors.....	57

3.3 Troubleshooting process.....	58
4. Water and oil shared sensor.....	58
5. Injector	58
6. Oxygen sensor.....	59
6.1 Detection	59
7. Ignition coil	59
8. Carbon canister solenoid valve.....	59
9. Fuel pump.....	59
10. OBD interface.....	60
11. MSE 6.0 ECU	60
1 2. Dump switch	61
Troubleshooting process.....	61
Disassembly	61
Examine	61
Engine cannot start and there is no sign of starting fault diagnosis process.....	62
Engine cannot start with motorcycle fault diagnosis process	62
Acceleration failure.....	63
High idle speed on hot motorcycle.....	63
Cooling motorcycle idling unstable.....	63
Unstable idling speed, easy to stall.....	64
EFI fault indicator light always on analysis flow chart.....	65
 4. Ignition system.....	66
Notice before service.....	66
Troubleshooting	67
Spark plug no spark.....	67
Ignition system layout.....	68
Ignition system electrical schematics	68
Ignition system inspection	69
Ignition coil	69
 5. Starting system.....	70
Notice before service.....	70
Troubleshooting	70
Starter motor does not run troubleshooting process:.....	70
1. Starter relay.....	70
2. Starter motor	71
3. The starting motor runs slowly.....	71
4. The starting motor works normally, but the engine cannot start	71
Starting system layout	71
Starting system electrical schematics	72
Starter motor	72
1. Remove the starter motor	72
2. Disassemble the starter motor	73
Examine	74
Starter motor front cover:.....	74
Starter motor rear cover:	74
Electrocution:	74
Check the starter relay.....	75
1. Operational inspection.....	75
2. Check the relay coil	75
2.1 Input Line	75
2.2 Ground Wire.....	75
3. Check the starting relay.....	75
4. Disassembly and assembly of the starting relay	76
 6. Fuel supply system	77
Notice before service.....	77
Fuel tank removal.....	78
1. Disassemble the fuel tank assembly	78
2. Remove the fuel pump.....	79

3. Remove the oil level sensor.....	79
4. Remove the external parts of the fuel tank assembly.....	79
Examine	80
1. Fuel pressure test.....	80
2. Fuel pump inspection.....	80
3. Oil level sensor.....	80
7. Cooling system	81
Notice before service.....	81
Troubleshooting	81
1. Engine temperature is too high	81
2. Engine temperature is too low:.....	81
3. Coolant leakage.....	81
Coolant system distribution diagram.....	82
Coolant flow diagram	82
Cooling system disassembly.....	83
Coolant system clamp /clamp distribution diagram	83
Thermostat assembly and small loop.....	84
Cooling system accessories.....	85
1. Main water tank.....	85
2. Water tank filling port	86
2.1 Overall sealing inspection	86
2.2 Pressure relief valve inspection.....	86
3. Auxiliary water tank	86
4. Water and oil shared sensor.....	86
5. Thermostat	86
5.1 Inspection.....	86
5.2 Fault phenomenon	86
5.3 Disassembly.....	87
6. Water pipes	87
7. Check the water pump cover assembly.....	87
8. Braking system	88
Notice before service.....	88
Troubleshooting	89
Brake handle soft.....	89
Brake handle hard.....	89
Disassembling the disc brake master cylinder and caliper	89
Disassembling the front disc brake master cylinder.....	89
Disassemble the rear disc brake master cylinder.....	90
Disassembling the front disc brake caliper	90
Disassemble the rear disc brake caliper	91
Wheel speed sensor and induction gear ring.....	91
9. Battery /Charging System	93
Notice before service.....	93
Troubleshooting	94
Charging system layout.....	95
Electrical Schematic.....	95
Battery disassembly and assembly.....	96
1. Disassembly	96
2. Inspection	96
3. Charging	96
Charging system inspection.....	96
1. Leakage test.....	96
2. Check the charging voltage.....	96
3. Inspection of magneto stator charging coil	97
10. Front fork assembly.....	98
Notice before service.....	98
Exploded view of the front fork assembly :.....	99

Exploded view of the steering wheel	99
Front fork exploded view	101
Lower connection board exploded view	102
Replace the steering wheel.....	103
1. Disassemble the handlebar assembly	103
2. Install the direction handle assembly.....	103
Replace the front wheel.....	104
1. Disassemble the front wheel assembly	104
2. Install the front wheel assembly	104
Exploded view of the front wheel assembly :	105
Front wheel assembly inspection and maintenance :.....	106
1. Disc brake	106
1.1 Service life of disc brakes	106
1.2 How to replace the disc brake.....	106
2. Front wheel oil seal and bearing.....	106
2.1 Service life of front wheel oil seal and bearing.....	106
2.2 How to replace the front wheel oil seal and bearing.....	106
3. Front wheel rim and tire.....	106
3.1 Service life of front wheel rim and tire	106
3.2 How to replace the front wheel rim and tire.....	106
3.3 Dynamic balancing.....	106
Replace the front shock absorber.....	107
1. Remove the front wheel and front fender assembly.....	107
2. Remove the left and right front shock absorbers.....	107
3. Reinstall the shock absorber, front fender, front wheel and other components	107
Replace the lower connecting board	108
1. Disassemble parts in advance.....	108
2. Remove the direction pad and upper connecting plate	108
3. Remove the lower connecting plate assembly	108
4. Install the lower connecting plate assembly.....	109
5. Install other disassembled components.....	109
11. Disassembly and assembly of vehicle covering parts	110
Removal of the hood	112
Removal of windshield instrument assembly.....	112
Disassembly of windshield instrument assembly.....	112
Removal of windshield lining	113
Removal of the upper rear trim cover	113
Removal of the head decoration	113
Removal of the fuel tank lock decorative cover and head side panel assembly.....	113
Removal of head lining and headlights.....	114
Removal of storage box.....	115
Removal of left and right rear armrests	115
Rear cover assembly removal.....	116
Removal of tail light assembly.....	116
Rear camera assembly removal.....	116
Removal of the tail cover trim.....	116
Removal of rear fender assembly.....	116
Removal of rear fender assembly.....	117
Removal of rear cover lining	117