## **Head Node**

Scott R Swindell | December 9, 2019 Node Does not Respond Node Check Wait for User do/Check next node –Power Up**⊳** GOSUB0/ user calls GOSUB(0) All Nodes Checked Node Settings do/SET\_NODE\_READY do/apply trajectory constants This is where normal operation for the head node begins. This includes homing and motion

control.