


Arduino Uno — All Parts Explained

A beginner-friendly reference guide explaining every component and interface highlighted in the Arduino Uno diagram.



Important: The diagram identifies the major parts visible on a standard Arduino Uno. Exact board revisions can have small physical differences.

1. Main Board Components

1. Reset Button

The Reset button restarts the ATmega328P microcontroller. When it is pressed, the Arduino begins running the uploaded program again from the beginning. It is useful when you want to restart a program without unplugging the board.

2. USB Type-B Port

The USB Type-B connector is used to connect the Arduino Uno to a computer. It can transfer programs to the board, provide serial communication, and supply power to the board. The USB cable is commonly used when uploading sketches from the Arduino IDE.

3. USB Interface Chip — ATmega16U2

The ATmega16U2 acts as the USB-to-serial interface between the computer and the main ATmega328P microcontroller. It converts USB communication from the computer into serial communication that the main microcontroller can use. It is also responsible for the Uno's USB serial interface.

4. 16 MHz Crystal Oscillator

The 16 MHz crystal oscillator provides a precise clock signal for the Arduino's main microcontroller. The clock determines the timing of processor operations and is important for functions such as `delay()`, `millis()`, serial communication, and PWM timing.

5. Voltage Regulator

The voltage regulator helps provide a stable supply voltage to the Arduino's electronics when power is supplied through the appropriate external power input. It prevents the board's supply from simply following the external input voltage.

6. DC Barrel Jack

The DC barrel jack allows the Arduino Uno to be powered from an external DC adapter. A commonly recommended input range is about 7–12 V. Higher input voltages can cause excessive heat in the regulator, so they should be avoided unless specifically supported.

7. Resettable Fuse (Polyfuse)

The resettable fuse provides protection against excessive current, especially on the USB power path. If too much current flows, the fuse increases its resistance and helps protect the board. After the problem is removed and the fuse cools, it can return to normal operation.

8. Digital Pins 0-13

The digital header provides 14 digital input/output pins, numbered 0 through 13. A pin can normally be configured as INPUT, OUTPUT, or INPUT_PULLUP. These pins are used for switches, LEDs, sensors, modules, and many other digital devices.

2. Pins, LEDs and Interfaces

9. PWM Pins — 3, 5, 6, 9, 10, 11

Pins marked with the ~ symbol support hardware PWM. PWM rapidly switches a digital output to create an adjustable average effect. It is commonly used for LED brightness and controlling the speed of some DC motors. On the Uno, `analogWrite()` uses PWM on these pins.

10. TX LED — Pin 1

The TX indicator shows serial transmission activity. It normally flashes when the Arduino sends serial data through the USB serial interface. Pin 1 is also the hardware serial TX pin of the ATmega328P.

11. RX LED — Pin 0

The RX indicator shows serial reception activity. It normally flashes when serial data is received through the USB serial interface. Pin 0 is the hardware serial RX pin of the ATmega328P.

12. Power LED

The ON or power LED indicates that the Arduino board has electrical power. If the board is powered through USB or an external power source, this LED normally lights up.

13. ICSP Header

ICSP stands for In-Circuit Serial Programming. The header provides access to SPI-related signals and programming connections. On the Uno, the ICSP connection associated with the ATmega328P is used for low-level programming and SPI access.

3. The Main Microcontroller

14. ATmega328P Microcontroller

This is the main microcontroller — the 'brain' of the Arduino Uno. It executes the program (sketch) uploaded by the user and controls the board's inputs and outputs. It contains the CPU, memory, timers, digital I/O, ADC, serial interfaces, and other peripherals.

ATmega328P — Key Specifications

Feature	ATmega328P (Arduino Uno)
Architecture	8-bit AVR
Clock	16 MHz
Flash	32 KB (program storage)
SRAM	2 KB
EEPROM	1 KB
Digital I/O	14 pins (0-13)
PWM	6 channels
ADC	10-bit, 6 analog inputs

4. Analog Input Pins A0-A5

The six analog input pins can measure varying voltages using the ATmega328P's built-in analog-to-digital converter (ADC). For a typical Uno operating at 5 V, `analogRead()` returns a 10-bit value from 0 to 1023 corresponding approximately to 0-5 V.

5. Power Header — Pin-by-Pin Explanation

The power header provides several useful power and control connections. It includes IOREF, RESET, 3.3V, 5V, GND, and VIN. These pins are used to power external circuits, reference logic levels, reset the board, or provide an external input voltage depending on the pin.

Pin	Meaning	Purpose
IOREF	I/O Reference	Provides the Uno's I/O voltage reference to compatible shields.
RESET	Reset	Pulling this pin LOW resets the microcontroller.
3.3V	3.3 V output	Provides a 3.3 V supply for suitable low-power circuits.
5V	5 V supply	Provides the board's regulated 5 V rail for suitable external circuits.
GND	Ground	Common electrical reference/return path.
VIN	Voltage input	External supply input to the board's power circuitry when used appropriately.

Quick Mental Model

ATmega328P = runs your program • 16 MHz oscillator = provides timing • Digital pins = ON/OFF style I/O • Analog pins = measure variable voltage • USB interface = communicates with your computer • Power section = supplies and protects the board.

For your current Arduino learning: focus first on `pinMode()`, `digitalRead()`, `digitalWrite()`, `analogRead()`, `analogWrite()`, `Serial.begin()`, `Serial.print()`, and the difference between digital input, analog input, and PWM output. Once these are comfortable, timers, interrupts, communication protocols, and sensors will become much easier to understand.