개발 환경 구성 (Turtlebot3 설치)


ROS 2 foxy SBC 설치

설치 참고 사이트

ROS 2 foxy 설치

3. 3. OpenCR Setup

- https://emanual.robotis.com/docs/en/platform/turtlebot3/sbc_s etup/#sbc-setup
- Foxy 를 반드시 선택 • 링크 접속 후 버전인



TurtleBot3 부팅디스크 생성

- microSD Card에 TurtleBot3 SBC Image를 저장함 (guide 3.2.1~3.2.5 참조)
 - 준비: microSD, TurtleBot3 SBC Image, image굽는 프로그램
 - PC에 microSD를 연결
 - 이미지 굽는 프로그램을 실행함
 - microSD에 Image를 저장함
 - GParted GUI tool을 활용해서 Partition을 확장함

TurtleBot3 WiFi Network 설정

- TurtleBot3의 WiFi Network를 설정
 - PC에 microSD를 연결
 - 다음 코드를 실행함
 - microSD 이름이 'writable'
- \$ cd /media/\$USER/writable/etc/netplan
- \$ sudo nano 50-cloud-init.yaml
 - nano 편집기 사용
 - 'WiFi_SSID'와 'WIFI_PASSWORD' 수정
 - 저장(Ctrl+S)하고 종료(Ctrl+X)함
 - 들여쓰기는 공백문자 두칸씩

```
network:
  version: 2
  renderer: networkd
  ethernets:
    eth0:
       dhcp4: yes
       dhcp6: yes
       optional: true
  wifis:
    wlan0:
       dhcp4: yes
       access-points:
       WIFI_SSID:
       password: WIFI_PASSWORD
```

TurtleBot3 IP 확인

- TurtleBot3 Raspberry Pi 부팅
 - 라즈베리파이 microHDMI 포트에 '**모니터**' 연결
 - 라즈베리파이 USB 포트에 '**키보드**' 연결
 - 라즈베리파이에 'microSD **카드**'를 삽입
 - TurtleBot3 '**파워**' 연결
 - 로그인 하기 id는 'ubuntu', password는 'turtlebot'
 - 부팅 종료 후 '**엔터키**' 클릭
 - ubuntu login: ubuntu
 - Password: turtlebot
- IP 확인
 - wlan0의 inet 이후 적힌 숫자들

\$ ifconfig

Remote PC에서 TurtleBot3 접속

- Remote PC의 터미널(Ctrl+Alt+T) 열기
- 다음 명령어를 입력한 후 접속
 - ssh ubuntu@{IP Address of Rasberry PI}

\$ ssh ubuntu@192.168.1.30

배치파일 수정 및 적용

■ 배치파일 확인

```
$ nano ~/.bashrc
```

- 배치파일 수정
 - 열린 배치파일에서 다음 내용을 추가한 후,
 - 저장(Ctrl+S)하고 종료(Ctrl+X)함

```
export ROS_DOMAIN_ID=30
TURTLEBOT3_MODEL=waffle_pi
LDS_MODEL=LDS-02
```

■ 배치파일 적용

\$ source ~/.bashrc

OpenCR 설치

- Remote PC에서 TurtleBot3 접속
- OpenCR 설치 (guide 3.3 참조)
- \$ sudo dpkg --add-architecture armhf
- \$ sudo apt update
- \$ sudo apt install libc6:armhf
- \$ export OPENCR_PORT=/dev/ttyACM0
- \$ export OPENCR_MODEL=waffle
- \$ rm -rf ./opencr_update.tar.bz2
- \$ wget https://github.com/ROBOTIS-GIT/OpenCR-Binaries/raw/master/turtlebot3/ROS2/latest/opencr_update.tar.bz2
- \$ tar -xvf ./opencr_update.tar.bz2
- \$ cd ~/opencr_update
- \$./update.sh \$OPENCR_PORT \$OPENCR_MODEL.opencr

Bringup

- Remote PC의 터미널(Ctrl+Alt+T) 열기
- \$ ssh ubuntu@192.168.1.30

- Bring up 실행
 - TurtleBot3의 모든 장치들을 구동함
 - 터미널에 'Run!'이 출력되면 Bringup 성공
- \$ ros2 launch turtlebot3_bringup robot.launch.py

설치 확인

TurtleBot3 Bringup

```
TurtleBot3를 Bringup한 후 다음 코드를 실행한 후 캡쳐함
$ ros2 topic list
$ ros2 service list
```

```
ubuntu@ubuntu: ~
                                                    ubuntu@ubuntu: ~ 115x5
[turtlebot3 ros-3] [INFO] [1690466829.246432636]
                                                  [turtlebot3 node]: Succeeded to create sound server
[turtlebot3 ros-3] [INFO] [1690466829.249593980] [turtlebot3 node]: Run!
[turtlebot3 ros-3] [INFO] [1690466829.290653677] [diff drive controller]: Init Odometry
[turtlebot3 ros-3] [INF0] [1690466829.301637308] [diff drive controller]: Run!
                                                                                ksh3717@teacher-com: ~ 57x29
                   ksh3717@teacher-com: ~ 56x29
                                                            ksh3717@teacher-com:~$ ros2 service list
ksh3717@teacher-com:~$ ros2 topic list
/battery_state
                                                            diff drive controller/describe parameters
/cmd vel
                                                            /diff drive controller/get parameter types
'imu
                                                            diff drive controller/get parameters
                                                             diff drive controller/list parameters
/joint_states
/magnetic field
                                                            diff drive controller/set parameters
                                                            diff drive controller/set parameters atomically
odom/
parameter events
                                                            /ld08 driver/describe parameters
                                                            /ld08 driver/get parameter types
robot description
rosout
                                                            /ld08 driver/get parameters
                                                            /ld08 driver/list parameters
scan
                                                             'ld08 driver/set parameters
sensor_state
                                                            /ld08_driver/set_parameters_atomically
tf static
                                                             motor power
```

TurtleBot3 움직임

터미널을 2개 열고 아래 코드를 각각 실행시킨 다음 TurtleBot3를 Remote의 키보드로 움직이고, 결과를 캡쳐함

- \$ ssh ubuntu@{IP_ADDRESS_OF_RASPBERRY_PI}
- \$ ros2 launch turtlebot3_bringup robot.launch.py
- \$ ros2 run turtlebot3_teleop teleop_keyboard

```
ksh3717@teacher-com: ~
                     ubuntu@ubuntu: ~ 56x23
                                                                               ksh3717@teacher-com: ~ 57x23
                                                            ksh3717@teacher-com:~$ ros2 run turtlebot3 teleop teleop
[turtlebot3 ros-3] [INF0] [1690466829.229300427] [turtle
bot3 node]: Succeeded to create battery state publisher
                                                           keyboard
[turtlebot3 ros-3] [INFO] [1690466829.233875629] [turtle
bot3 node]: Succeeded to create imu publisher
                                                            Control Your TurtleBot3!
[turtlebot3 ros-3] [INFO] [1690466829.237156695] [turtle
bot3 node]: Succeeded to create sensor state publisher
                                                           Moving around:
[turtlebot3 ros-3] [INFO] [1690466829.239867876] [turtle
bot3 node]: Succeeded to create joint state publisher
[turtlebot3 ros-3] [INFO] [1690466829.240001282] [turtle
bot3 node]: Add Devices
[turtlebot3_ros-3] [INFO] [1690466829.240043634] [turtle
                                                           w/x : increase/decrease linear velocity (Burger : \sim 0.22,
bot3 node]: Succeeded to create motor power server
                                                            Waffle and Waffle Pi : ~ 0.26)
[turtlebot3_ros-3] [INFO] [1690466829.243493346] [turtle
                                                           a/d : increase/decrease angular velocity (Burger : ~ 2.84
bot3 node]: Succeeded to create reset server
                                                             Waffle and Waffle Pi : ~ 1.82)
[turtlebot3_ros-3] [INFO] [1690466829.246432636] [turtle
bot3 node]: Succeeded to create sound server
                                                            space key, s : force stop
[turtlebot3 ros-3] [INFO] [1690466829.249593980] [turtle
bot3 node]: Run!
                                                           CTRL-C to quit
[turtlebot3_ros-3] [INFO] [1690466829.290653677] [diff_d
rive controller]: Init Odometry
                                                           currently:
                                                                           linear velocity 0.01
                                                                                                     angular velocity
[turtlebot3_ros-3] [INFO] [1690466829.301637308] [diff d
                                                            0.0
rive controller]: Run!
                                                           currently:
                                                                           linear velocity 0.02
                                                                                                     angular velocity
```

Topic Monitor

TurtleBot3를 움직이며 다음 ROS 도구를 실행한 후 변화를 캡쳐함

\$ rqt

[Plugins]-[Topics]-[Topic Monitor] 메뉴 클릭 '/odom' 왼쪽 체크 후 header, pose, twist의 모든 값을 연 후 값의 변화를 확인함

