

- `setup()` and `loop()` :

- `setup()` :

- Runs once when the Arduino starts or resets.
 - Used to initialize pins, sensors, serial communication, etc.

- `loop()` :

- Runs repeatedly forever after `setup()`.
 - Contains the main code that performs tasks continuously.

- If you put a long `delay()` inside `loop()` :

- The program will pause during the delay time.
 - During this time, Arduino cannot read sensors or respond to new data.
 - This makes sensor reading slow and unresponsive.

- Non-blocking alternative :

- Use `millis()` function to track time without stopping the program.
 - This allows Arduino to keep reading sensors and doing other tasks while waiting.