

SEE HOW IT WORKS

Demonstrational Video is Available on our website: www.powertrainsavers.com

CONTENTS

Important Information
Order Chart: 1300, 1400 & 1500 (small) series2 Torque Capacities from 2,000 - 8,500 ft/lbs
Power Train Saver & Torque Fuse set-ups & Options for 1300, 1400 & 1500 (small) series
Order Chart: 1500 (<i>large</i>), 1600, 1700, 1800 & *SPL series3 Torque Capacities from 5,500 - 25,500 ft/lbs
Power Train Savers & Torque Fuse set-ups & Options for 1500 (large), 1600, 1700, 1800 & *SPL series
Installation Instructions for Weld-In <u>Bushing</u> Units4
Installation Instructions for Weld-In <u>Bearing</u> Units12
Welding Procedure5
Torque Fuse [®] Installation Drive-shaft Units
Well Service Pump Specifications
Part Numbers for Industrial Flange Units
Part Numbers for Industrial Flange Units
Part Numbers for Industrial Weld-In Bearing Units11
Torque Fuse Troubleshooting

SAFETY PRECAUTIONS

- The Power Train Saver must be installed by a qualified driveline mechanic. (See Page 4)
- Torque Fuses must be installed with the truck or equipment shut off and brakes locked on. (See Page 6 & 7)
- Torque Fuses must be torqued down to the specifications listed in this catalogue. (See Page 6 & 7)
- Do not preheat the Power Train Saver. (See page 5)

Power Train Savers®
Box 901, Vauxhall, Alberta T0K 2K0
Ph: (403) 654-2800 Fax: (403) 654-2811
Website: www.powertrainsavers.com

PowerTrainSaver® US PAT. #5651629 / #6764404

Torque Fuses® CAN PAT. #2174259