


TORQUE CONVERTER COMPONENTS



Damper Eliminator Kit



INSTALLATION INSTRUCTIONS

- 1. Remove the stock AOD direct drive damper from the front cover.
- Weld the FD-HTCM-26 onto the front cover side of the turbine hub (FD-HTCM-10 for the race kit, FD-HT-AOD for a stock converter). Note: This will NOT work with the OEM powdered metal turbine hub.
- 3. Install the turbine hub assembly into the turbine and weld or rivet the assembly together.
- 4. Install the front cover bushing, **FD-B-5**, into the front cover. This bushing is designed to fit into the bore.
- 5. Due to size variations in the OEM stamped covers, building up and sizing the bore is required. The bore should be sized to 1.174" ± .001".
- 6. Install the plastic washer, **FD-WP22-OE**, and the turbine assembly into the front cover and finish assembling the converter as normal.

