SOTRUST S68

Magnetic Switch Keyboard

Quick Start & User Manual

Driver installation · Per-key actuation · Rapid Trigger
Lighting · Firmware updates · Troubleshooting

Version 1.0 · October 2026 · English

Model S68 · 68-key · Wired USB-C

www.sotrust.net

SECTION 1

Before you start

The S68 is a wired keyboard. It works the moment you plug it in — the driver is optional and only needed for per-key customization. This manual covers connection, driver installation, the main software features, firmware updates and troubleshooting.

In the box

- S68 magnetic switch keyboard × 1
- USB-C to USB-A cable, 1.55 m × 1

There is no USB receiver and no battery — none is required.

Connection (S68)

The S68 is a wired keyboard. Connect it to your computer with the included USB-C to USB-A cable — no receiver, no pairing, no battery. Plug it in and it works immediately; the software is optional and only needed for customization.

- Use a USB-C cable that supports **data transfer**. Charge-only cables are not detected.
- The keyboard end is USB-C and the computer end is USB-A. If your computer only has USB-A ports, the included cable connects directly.
- No 2.4G, Bluetooth or wireless mode. No receiver is needed or included.
- Earlier printed manuals mentioned a 2.5GHz wireless mode — that was a documentation error and has been corrected. The S68 has never had a wireless version.

> **What the S68 is not:** there is no wireless mode, no Bluetooth pairing and no dongle. If a review, listing or manual you have seen mentions wireless, it does not apply to this model.

SECTION 2

Quick start

From unboxing to a fully customized keyboard in three steps — typically under two minutes. No registration and no password are required for any download.

1

Download and run the driver installer

Go to www.sotrust.net/software and choose the build for your system: Windows (one installer covers all S68 units), or macOS (Apple silicon / Intel). Links are direct — no sign-up and no password.

2

Close other keyboard software, then follow the on-screen steps

Quit any other keyboard utility first so it cannot grab the device. Windows: an administrator account is required. macOS: the app is signed and notarized by Apple, so a normal double-click is enough.

3

Connect the keyboard with the included USB-C to USB-A cable

Open SOTRUST S68 Setup to set per-key actuation, Rapid Trigger, deadzone, macros and lighting. Settings are saved to the keyboard's onboard memory.

Platform notes

- **Windows 10 / 11 (64-bit):** .NET Framework 4.8 is already included — just run the installer.
- **Windows 7 SP1 / 8.1:** install .NET Framework 4.8 first, then run the installer.
- **macOS 12 Monterey or later:** pick the Apple silicon build (M1–M4) or the Intel build. Check Apple menu → About This Mac: “Chip” means Apple silicon, “Processor” means Intel.
- **“Unknown publisher” on Windows:** the installer is not yet code-signed. Verify the SHA-256 shown on the download page before running it, and only download from www.sotrust.net/software or our official GitHub release page.

S68 connects with a cable only — there is no wireless mode.

SECTION 3

Using the software

SOTRUST S68 Setup is the configuration app for Windows and macOS. Every setting below is stored on the keyboard, so profiles travel with the device.

Per-key actuation	Set the actuation point of each key individually. Trigger precision is adjustable in 0.01 mm steps, so a key can react at the lightest touch or deliberately deeper.
Rapid Trigger (RT)	Resets and re-arms a key the instant it starts moving in either direction. RT precision is adjustable down to 0.01 mm, and sensitivity can be tuned per key.
Deadzone	Top and bottom deadzones are adjustable in the driver, per key or globally. Adjust them when light taps or resting fingers trigger a key unintentionally.
DKS / MT / TGL	Advanced key actions: multiple actions from one key at different travel depths (DKS), a key that acts as modifier when held and a normal key when tapped (MT), and a toggle key (TGL).
Macros	Record key sequences with the macro manager, assign them to any key and store them on the keyboard's onboard memory.
Lighting	Per-key RGB with 16.8 M colors and 15 built-in effects, plus a per-key color picker.
Profiles	Save configurations for different games and switch between them without reopening the app.
Firmware	Firmware updates (current: v0.0.03) are delivered inside SOTRUST S68 Setup — connect the keyboard and the tool checks for updates automatically. There is no separate firmware file to install.
SOTRUST PIANO	A separate companion app (Windows) that maps key travel to notes and dynamics, so the S68 can be played like an instrument.

SECTION 4

Troubleshooting

Six questions cover almost every support ticket. If none of them solves your issue, email liuke@sotrust.net with your order number and operating system.

1. Windows shows “Unknown publisher” — is it safe?

Our installer is digitally signed by SOTRUST; you can verify this in the file properties under Digital Signatures. Until the signed build is published, compare the SHA-256 of the downloaded file with the value listed on www.sotrust.net/software — if they match, the file is intact and unmodified.

2. Does the S68 support wireless or Bluetooth?

No. The S68 is a wired keyboard and connects only with the included USB-C to USB-A cable. There is no 2.4G, Bluetooth or wireless mode, and no receiver is needed or included. Earlier printed manuals mentioned a 2.5GHz wireless mode — that was a documentation error and has been corrected.

3. The keyboard is not detected.

Use a USB-C cable that supports data transfer (charge-only cables do not carry data), try another USB port, and close other keyboard software before connecting. On macOS, reconnect the keyboard after installing the driver.

4. Does it work with macOS?

Yes. Both Apple silicon and Intel Macs are supported, and the macOS app is signed and notarized by Apple — it opens with a normal double-click, with no security warning.

5. Do I need the software?

No. The keyboard works plug-and-play. Install the driver only if you want per-key actuation, Rapid Trigger, macros or lighting control.

6. Which file should I download?

One Windows driver covers all S68 units. Mac users pick the Apple silicon or Intel build. The manual is device-specific — choose S68.

SECTION 5

Specifications

Brand / model	SOTRUST™ S68
Switch type	Hall-effect magnetic, hot-swappable
Layout	68-key compact
Trigger precision	0.01 mm, per key, adjustable
Rapid Trigger precision	Adjustable down to 0.01 mm
Deadzone	Adjustable (top & bottom, set in driver)
Polling rate	1000 Hz
Single-key scan	4K
Response	1 ms
Connection	USB-C (keyboard) to USB-A (computer), wired only — no wireless, no Bluetooth
Cable length	1.55 m (included)
Positioning plate	FR4 black-core
Padding	4-layer — Poron + IXPE + PET + Poron
RGB	16.8 M colors, per-key, 15 effects
Custom keys	DKS / MT / TGL
Trigger modes	Global / Single key / Rapid Trigger
Macros	Driver macro + macro manager
Onboard memory	Profiles stored on the keyboard
Driver	SOTRUST S68 Setup — Windows & macOS
Firmware	v0.0.03, updated through SOTRUST S68 Setup
Compliance	FCC / CE / RoHS

SECTION 6

Support

Downloads, driver versions and the latest manual: **www.sotrust.net/software**
Support and warranty: **liuke@sotrust.net**
Company: Nanjing Xingui Yuanying Trading Co., Ltd.

SOTRUST™ is a pending trademark. Specifications are subject to change without notice; the values in this manual reflect actual measured performance. © 2026 Nanjing Xingui Yuanying Trading Co., Ltd. All rights reserved.