

Nimbus Smart Thermostat - Frequently Asked Questions

Setup

Q: How do I connect the Nimbus thermostat to Wi-Fi?

A: Open the Nimbus app, tap Add Device, and follow the prompts. The thermostat only supports 2.4 GHz Wi-Fi networks. 5 GHz networks are not supported.

Q: Which wires does the thermostat need?

A: It requires a C-wire (common wire). If your system has no C-wire, use the included power adapter kit.

Troubleshooting and warranty

Q: How do I factory reset the thermostat?

A: Hold the centre dial for 15 seconds until the display shows the word RESET, then release. All schedules and Wi-Fi settings will be erased.

Q: What does the flashing red light mean?

A: A flashing red light means the battery backup is low. Replace it with a CR2032 battery.

Q: What is the warranty period?

A: The Nimbus thermostat has a 2-year limited warranty. Damage from incorrect installation is not covered.