Renesas Starter Kit for RX130 CPU Board Schematics

PAGE	DESCRIPTION
1	INDEX
2	RX130 Microcontroller
3	PSU, Reset, Switches, LEDs, MCU Mode Setting
4	MCU Pin Function Select, Application Headers
5	E1, USB to Serial Interface
6	Pmod Interface, Touch Interface
7	IIC EEPROM, LIN
8	Microcontroller Pin Headers

Note:

C : Capacitor D : Diode

R: Fixed Resistor RV: Potentiometer U: Integrated Circuit X: Crystal, Oscillator RES: Reset Switch

SW: Switch

LED : Light Emitting Diode

PWR : Power Jack
J : Connector, Jumper


Board Code:


RTK5005130C00000BE: MP Board


REEL Drawing No. D014342_04


Ren	Renesas System Design Co., Ltd.						
Title	RSKRX130 [Index]					_	
Size	Document Number R20UT3443EG0100				F	če	
Date	Wadnesday October 20, 2015	Chast			•	-	


^{* &}quot;DNF" marking means that component is not fitted by default.

















Renesas System Design Co., Ltd. RSKRX130 [IIC EEPROM, LIN) Document Number R20UT3443EG0100 Wednesday, October 28, 2015

