

FreeSoC2 (Dev-13229)


Arduino Configuration

Name	Arduino	Serial
Power	Port	Ext Int
GND	ADC	SIO
Control	PWM	

Power
 Vin = 2.5V-12V
 VDDIO = 3.3V or 5V
 5V @ 500mA/ 3.3V @ 500mA

Buttons
 Debugger Reset
 Debugger button (P2.2)
 Target Reset
 Target Button (P1.2)

	NC	VDDIO	Arduino
VDDIO2	Reset	Reset	
3.3V	3.3V		
5V	5V		
GND	GND		
GND	GND		
Vin	V_IN		
A0	P15.5	A0	A0
A1	P15.4	A1	A1
A2	P6.3	A2	A2
A3	P6.2	A3	A3
SDA	A4	P6.1	A4
SCL	A5	P6.0	A5
	GND	GND	
	VDDIO	VDDIO	
SIO	P12.0	SIO P12.0	
SIO	P12.1	SIO P12.1	
SIO	P12.2	SIO P12.2	
SIO	P12.3	SIO P12.3	
SIO	P12.6	SIO P12.6	
SIO	P12.7	SIO P12.7	
GND	GND	GND	
VDDIO	VDDIO	VDDIO	
5.6	5.6	5.7	5.7
5.4	5.4	5.5	5.5
5.2	5.2	5.3	5.3
5.0	5.0	5.1	5.1



LEDs

Debugger LED (lit if can't detect a host; flash during data transfer)
 User LED: D13/P6.7

3.0	Debugger	GND	GND
12.7	Debugger	12.6	Debugger
3.7	Debugger	3.6	Debugger
3.5	Debugger	3.4	Debugger
0.1	Debugger	0.0	Debugger
1.2	Debugger	VDDIO	VDDIO
A4	A4	P6.4	A4
A5	A5	P6.8	A5
NC			

GND	D13	P6.7	SCK
D13	D12	P6.6	MISO
D12	D11	P6.5	PWM MOSI
D11	D10	P6.4	PWM CS
D10	D9	P12.5	PWM
D9	D8	P12.4	
D8	D7	P2.7	
D7	D6	P2.6	PWM
D6	D5	P2.5	PWM
D5	D4	P2.4	
D4	D3	P2.3	PWM INT1
D3	D2	P2.2	INT0
D2	D1	P2.1	TX
D1	D0	P2.0	RX

GND	GND	GND	GND
VDDIO	VDDIO	VDDIO	VDDIO
4.6	4.6	4.7	4.7
4.4	4.4	4.5	4.5
4.2	4.2	4.3	4.3
4.0	4.0	4.1	4.1
GND	GND	GND	GND
VDDIO	VDDIO	VDDIO	VDDIO
0.7	0.7	0.6	0.6
0.5	0.5	0.4	0.4
0.3	0.3	0.2	0.2
0.1	0.1	0.0	0.0