HM-10/11 Self-Learning Function Introduction

The communication of BLE is based on the UUID and properties of UUID to be accomplished. However, the manufacturer generally created their own unique UUID, which means it would be unable tocommunicate between different UUIDs. In order to solve the the the theorem and th

1. What kind of modules can use the new self-learning feature of V542?

The new learning function can help with the communication of your BLE devices automatically when your devices using with all following satisfying using requirements. With the following conditions the self-learning feature of HM-10/11 can be sued, otherwise cannot.

NOTE: Normally, the UUID data can be accessed by using LightBlue tools, or you can ask the BLE device provider directly.

Since V605, you can use AT+LN command to talk with the modules directly. If your version is lower than V605, Please use HMConfigAssistan software to get AT Command List.p

If your current BLE device is using 128Bit UUID, Please use

HMConfigAssistan.exe to create AT Commands List (Required V549 or higher). 16Bit UUID device also could use that tool to create AT Commands List.(Required V545 or higher)

The follow documents is show you how to config by yourself.

- 1.1 While your current BLE device is using 16Bit UUID to implement communication such as 0xFFE0, the new feature can be used.
- 1.2 While the transmit-receive UUID of the characteristic of your current BLE device is only one (as shown in figure 1.1) or only tow (as shown in figure 1.2)



Figure 1.1. only one UUID



Figure 1.2. two UUIDs

1.3 If your current BLE device is slave device, you should use

HM-10/11 as the master device.

- 2. How to use V542 self-learning function
 - 2.1 Configuration Process
 - 2.1.1 AT+RENEWà Restore to factory defaults
 - 2.1.2 AT+IMME1à Set theHM-10/11 under manual operation mode
 - 2.1.3 AT+COMP1àTurn on HM-10/11 self-learning function
 - 2.1.4 AT+UUID0x1234à This 0x1234 is the characteristic of your current BLE slave module which include Write property or Write-Without-Responseproperty of UUID.
 - 2.1.5 AT+CHAR0x5678à This 0x5678 is the characteristic of your current BLE slave module which is Notify property of UUID.

 NOTE: If there is only one single UUID of Characteristic of your current BLE module which the UUID simultaneously integrate Write, Write-Without-Response and Notify, you can set up the same UUID of AT+UUID and AT+CHAR.
 - 2.1.6 AT+SHOW1à Only you would like to back to the BLE slave modulename when you are searching, please execute this command. This is an optional command.
 - 2.1.7 AT+ROLE1à Set up HM-10/11 to main mode
 - 2.1.8 The Configuration Process complete. This process only

need to set up once.

- 2.2 Searchingand Connecting Process
 - 2.2.1 AT+DISC? à Execute the command
 - 2.2.2 Receive OK+IDSCSà Start searching
 - 2.2.3 Receive OK+DIS<P1>:<P2>à Find the returned value of one device.

P1: Device type. The possible values: are 0, 1, 2.

P2: MAC address of device. Format: 00112233445566

- 2.2.4 Receive OK+DISCEà Searching completed
- 2.2.5 Use the command 'AT' which in AT+CO<P1><P2> to try to connect the found device
- 2.2.6 Receive OK+CO<P1><P1><P3>,the 'start connecting command' .

P1: Device Type

P3: Connection Status. A: Accepting Request, Starting Connecting. E: Invalid Address

2.2.7 Receive the return information from the connection results OK+CONN or OK+CONNF

OK+CONNà Connection Succeed

OK+CONNFà Connection fail

2.2.8 Communication starts, Transceiver Data

2.2.9 Communication complete. Send 'AT' for disconnected

NOTE1:If you turn on the self-learning function, there will no impact on the communication between any other BLE products of HM series.

NOTE2:If you have the device type and MAC address, you could ignore the searching steps and directly use 'AT+CO' command to do the connection.

NOTE3: After configuration, you also could use 'AT+IMMEO' to get the HM-10/11 working in automatic mode.

Jinan Huamao Technologies Co Ltd support@jnhuamao.cn