Direction "from"

Key	Value	Meaning
errorCode	251 ... 255, step 1	Error code from supply voltage byte
	noError	No error reported
motionDetected	false	PIR off
	true	PIR on
supplyVoltage	0 ... 5 [V], step 0.02	Supply voltage / super cap. (linear)