Direction "from"

Key	Value	Meaning
errorCode	251 ... 255, step 1	Error code from supply voltage byte
	noError	No error reported
illumination	0 ... 1000 [lx], step 1	Illumination (linear)
	overRange	Illumination is over sensor range
motionDetected	false	Uncertain of occupancy status
	true	Motion detected
supplyVoltage	0 ... 5 [V], step 0.02	Supply voltage / super cap. (linear)