Direction "from"

Key	Value	Meaning
setpoint	0 ... 63, step 1	Set point (manufacturer specific)
temperature	-10 ... 41.2 [°C], step 0.05	Temperature (linear)