Direction "from"

Key	Value	Meaning
errorCode	251 ... 255, step 1	Error code from supply voltage byte
	noError	No error reported
fanSpeed	auto	Fan speed auto
	off	Fan is off
	speed0	Fan speed 0
	speed1	Fan speed 1
	speed2	Fan speed 2
	speed3	Fan speed 3
	speed4	Fan speed 4
	speed5	Fan speed 5
occupancyButton	pressed	Button is pressed
	released	Button is released
occupancyEnabled	false	Occupancy is disabled
	true	Occupancy is enabled
supplyVoltage	0 ... 5 [V], step 0.02	Supply voltage (linear)
temperature	0 ... 40 [°C], step 0.16	Temperature (linear)
temperatureSetpoint	0 ... 40 [°C], step 0.16	Temperature Set Point (linear)