Direction "from"

Key	Value	Meaning
batteryLow	false	Battery is OK
	true	Battery is low
setpoint	0 ... 255, step 1	Set point (manufacturer specific)
setpointMode	auto	Automatic control (e.g. defined by time program)
	frost	Frost protection
	setpoint	Room temperature is defined by Set point
temperature	0 ... 40 [°C], step 0.16	Temperature (linear)
userActivity	false	No user intervention action on device
	true	User intervention action on device