### Direction "from"

| Key | Value | Meaning |
|---|---|---|
| angle | -180 ... 180 [°], step 2 | Current angle |
| endPosition | closed | Blind fully closed |
| | notReached | No End-position reached |
| | open | Blind fully open |
| | unavailable | No End-position available |
| errorCode | failure | Internal failure |
| | noEndPosition | End-positions are not configured |
| | noError | No error present |
| movement | closing | Blind closes |
| | noStatus | No Status available |
| | opening | Blind opens |
| | stopped | Blind stopped |
| position | 0 ... 100 [%], step 1 | Current position of the blind |
| serviceMode | false | Normal mode |
| | true | Service mode is activated (For example for maintenance) |