Direction "from"

Key	Value	Meaning
dimming	0 ... 255, step 1	Dimming output level (manufacturer specific)
errorCode	external	Failure on the external periphery
	internal	Internal failure
	lamp	Lamp-failure
	noError	No error is present
operatingHours	0 ... 65535 [h], step 1	Lamp operating hours
serviceMode	normal	Normal mode is activated
	service	Service mode is activated
status	off	Lighting is off
	on	Lighting is on

Direction "from"

Key	Value	Meaning
blue	0 ... 255, step 1	Blue value
errorCode	external	Failure on the external periphery
	internal	Internal failure
	lamp	Lamp-failure
	noError	No error is present
green	0 ... 255, step 1	Green value
red	0 ... 255, step 1	Red value
serviceMode	normal	Normal mode is activated
	service	Service mode is activated
status	off	Lighting is off
	on	Lighting is on

Direction "from"

Key	Value	Meaning
amperage	0 ... 6553.5 [A], step 0.001	Amperage
energy	0 ... 65535000000000 [Wh], step 1	Energy
errorCode	external	Failure on the external periphery
	internal	Internal failure
	lamp	Lamp-failure
	noError	No error is present
power	0 ... 65535000000 [W], step 0.001	Power
serviceMode	normal	Normal mode is activated
	service	Service mode is activated
status	off	Lighting is off
	on	Lighting is on
voltage	0 ... 6553.5 [V], step 0.001	Voltage