Direction "from"

Key	Value	Meaning
channel	0 ... 15, step 1	Measurement channel
cumulativeCounter	0 ... 16777215, step 0.001	Cumulative counter value

Direction "from"

Key	Value	Meaning
channel	0 ... 15, step 1	Measurement channel
currentCounter	0 ... 16777215 [1/s], step 0.001	Current counter value