Direction "from"

Key	Value	Meaning
hemisphere	north	North
	south	South
sunEast	0 ... 150000 [lx], step 588.235	Sun - East,linear
sunSouth	0 ... 150000 [lx], step 588.235	Sun - South,linear
sunWest	0 ... 150000 [lx], step 588.235	Sun - West,linear