Direction "from"

Key	Value	Meaning
contact	closed	Contact closed
	open	Contact open
errorCode	251 ... 255, step 1	Error code from supply voltage byte
	noError	No error reported
supplyVoltage	0 ... 5 [V], step 0.02	Supply voltage (linear)