Direction "from"

Key	Value	Meaning
contact	closed	Contact closed
	open	Contact open
errorCode	251 ... 255, step 1	Error code from supply voltage byte
	noError	No error reported
illumination	0 ... 1000 [lx], step 4	Illumination (linear)
	overRange	Illumination is over sensor range
supplyVoltage	0 ... 5 [V], step 0.02	Supply voltage (linear)