Direction "from"

Key	Value	Meaning
errorCode	251 ... 255, step 1	Error code from supply voltage byte
	noError	No error reported
supplyVoltage	0 ... 5 [V], step 0.02	Supply voltage (linear)
vibration	false	No vibration detected
	true	Vibration detected