Direction "from"

Key	Value	Meaning
actuatorObstructed	false	Actuator is free
	true	Actuator is obstructed
batteryLow	false	Battery does not need to be changed
	true	Change battery in the next days
contact	closed	Contact or cover is closed
	open	Contact or cover is open
energyInput	false	Energy input is disabled
	true	Energy input is enabled
energyStorageCharged	false	Energy storage needs to be charged
	true	Energy storage is sufficiently charged
serviceMode	off	Service is off
	on	Service is on
temperature	0 ... 40 [°C], step 0.157	Temperature (linear)
	overRange	Temperature sensor failure or out of range
valve	0 ... 100 [%], step 1	Current valve position
window	closed	Normal operation
	open	Open window detected

Direction "to": Control actuator via valve position

Key	Value	Meaning
setpointInverse	false (default)	Set point is normal
	true	Set point is inversed
summerMode	false (default)	Summer mode is deactivated
	true	Summer mode is activated
valve	0 ... 100 [%], step 1	Valve position

Direction "to": Control actuator via temperature

Key	Value	Meaning
summerMode	false (default)	Summer mode is deactivated
	true	Summer mode is activated
temperature	0 ... 40 [°C], step 0.157	Temperature from room control unit (RCU)
temperatureSetpoint	0 ... 40 [°C], step 0.157	Temperature set point

Direction "to": Service mode

Key	Value	Meaning
runInitSequence	false (default)	Do not run init sequence
	true	Run init sequence
runLiftSet	false (default)	Done with initialization
	true	Initialization is running
valveMaintenance	close	Close valve
	noChange (default)	Do not move valve after init sequence or lift set
	open	Open valve