Direction "from"

Key	Value	Meaning
setpointInverse	false	State of set point inverse (manufacturer specific)
	true	State of set point inverse (manufacturer specific)
valve	0 ... 100 [%], step 1	Actual value (linear) can be a linear or rotation motion

Direction "to"

Key	Value	Meaning
setpointInverse	false	State of set point inverse (manufacturer specific)
	true	State of set point inverse (manufacturer specific)
valve	0 ... 100 [%], step 1	Value to set for the valve (linear)