Direction "from"

Key	Value	Meaning
errorCode	batteryEmpty	Battery is empty
	blockedValve	Blocked valve
	endpointDetectionError	End point detection error
	frostProtection	Frost protection
	measurementError	Measurement error
	noError	No error reported
	noReponseFromController	No response from controller
	noValve	No valve
	notTaughtIn	Not taught in
	teachInError	Teach-in error
feedTemperature	20 ... 80 [°C], step 0.235	Current feed temperature value
locked	false	Manual room temperature selection enabled
	true	Manual room temperature selection disabled
measurement	off	Measure feed + room temperature is inactive
	on	Measure feed + room temperature is active
query	noChange	No change
	status	Status requested
roomTemperature	10 ... 30 [°C], step 0.078	Current room temperature
temperatureSetpoint	10 ... 30 [°C], step 0.078	Current temperature set point
valve	0 ... 100 [%], step 1	Current valve position

Direction "to"

Key	Value	Meaning
command	closeValve	Close valve
	noChange (default)	No change
	openValve	Open valve
	runInit	Run initialisation
displayOrientation	0 ... 270 [°], step 90 (default 0)	Adjusts the display orientation
locked	false (default)	Manual room temperature selection enabled
	true	Manual room temperature selection disabled
measurement	off	Disable measurement for energy saving
	on (default)	Enable feed + room temperature measurement
temperatureSetpoint	10 ... 30 [°C], step 0.078	Temperature set point
valve	0 ... 100 [%], step 1	Valve position
wakeUpCycle	30 ... 1500 [s], step 30 (default 600)	Cyclic wake-up time, 30 secs - 25 min in 30 seconds steps
	10800 ... 151200 [s], step 10800	Cyclic wake-up time, 3-42 hours in 3 hours steps
	10	Minimal cyclic wake-up time = 10 seconds