Direction "from": Operation mode: Temperature control

Key	Value	Meaning
actuatorObstructed	false	Actuator operating normally
	true	Actuator is obstructed
energyInput	false	No energy is harvested
	true	Energy is being harvested
energyStorageCharged	false	Energy storage needs to be charged
	true	Energy storage is sufficiently charged
feedTemperature	0 ... 80 [°C], step 0.5	The feed temperature sensor is used
radioError	false	radio communication is stable
	true	6 or more consecutive radio communication errors have occurred
radioSignalStrength	false	Radio signal is strong
	true	Radio signal is weak (-77dBm or less)
temperature	0 ... 40 [°C], step 0.5	The local ambient temperature is used
temperatureSetpoint	0 ... 40 [°C], step 0.5	Current temperature setpoint plus / minus local offset are communicated as an absolute temperature value [°C]
valve	0 ... 100 [%], step 1	Current valve position
window	closed	Normal operation
	open	Open window detected

Direction "from": Operating Mode: Valve Position Control

Key	Value	Meaning
actuatorObstructed	false	Actuator operating normally
	true	Actuator is obstructed
energyInput	false	No energy is harvested
	true	Energy is being harvested
energyStorageCharged	false	Energy storage is discharged
	true	Energy storage is sufficiently charged
feedTemperature	0 ... 80 [°C], step 0.5	The feed temperature sensor is used
radioError	false	radio communication is stable
	true	6 or more consecutive radio communication errors have occurred
radioSignalStrength	false	Radio signal is strong
	true	Radio signal is weak (-77dBm or less)
setpointShift	-5 ... 5 [°C], step 1	Local offset setting is communicated directly
temperature	0 ... 40 [°C], step 0.5	The local ambient temperature is used
valve	0 ... 100 [%], step 1	Current valve position
window	closed	Normal operation
	open	Open window detected

Direction "to": Control actuator via valve position

Key	Value	Meaning
communicationIntervall	10minutes	Radio duty cycle 10 min
	120minutes	Radio duty cycle 120 min
	20minutes	Radio duty cycle 20 min
	2minutes	Radio duty cycle 2 min
	30minutes	Radio duty cycle 30 min
	5minutes	Radio duty cycle 5 min
	60minutes	Radio duty cycle 60 min
	auto (default)	Radio duty cycle default time set
temperatureSelection	ambientTemperature (default)	ambient temperature is requested
	feedTemperature	feed temperature is requested
valve	0 ... 100 [%], step 1	Valve position setpoint (0 - 100%) requested by controller

Direction "to": Run actuator-internal temperature control loop with RCU providing room temperature

Key	Value	Meaning
communicationIntervall	10minutes	Radio duty cycle 10 min
	120minutes	Radio duty cycle 120 min
	20minutes	Radio duty cycle 20 min
	2minutes	Radio duty cycle 2 min
	30minutes	Radio duty cycle 30 min
	5minutes	Radio duty cycle 5 min
	60minutes	Radio duty cycle 60 min
	auto (default)	Radio duty cycle default time set
temperature	0 ... 40 [°C], step 0.25	Temperature communivcated by RCU
temperatureSelection	ambientTemperature (default)	ambient temperature is requested
	feedTemperature	feed temperature is requested
temperatureSetpoint	0 ... 40 [°C], step 0.5	Target temperature as requested by RCU

Direction "to": Run actuator-internal temperature control loop, room temperature is estimated based on the actuator's internal sensors

Key	Value	Meaning
communicationIntervall	10minutes	Radio duty cycle 10 min
	120minutes	Radio duty cycle 120 min
	20minutes	Radio duty cycle 20 min
	2minutes	Radio duty cycle 2 min
	30minutes	Radio duty cycle 30 min
	5minutes	Radio duty cycle 5 min
	60minutes	Radio duty cycle 60 min
	auto (default)	Radio duty cycle default time set
temperatureSelection	ambientTemperature (default)	ambient temperature is requested
	feedTemperature	feed temperature is requested
temperatureSetpoint	0 ... 40 [°C], step 0.5	Target temperature as requested by RCU

Direction "to": Cofiguration mode

Key	Value	Meaning
command	noChange (default)	Normal operation
	runReference	Execute reference-run, then revert to normal operation
standByMode	false (default)	Normal operation
	true	Enter standby mode (manually turn dial to wake up from standby)
summerMode	false (default)	Normal operation
	true	Summer mode is activated (radio communication every 8h only)