Direction "both"

Key	Value	Meaning
controlVariableOverride	0 ... 100 [%], step 0.392	Liner control valve override percentage
	noChange (default)	Leave previous settigns (no change)
controllerMode	autoMode	Controller auto mode
	cooling	Controller cooling mode
	heating	Controller heating mode
	off	Controller off
energyHoldOffDewPoint	false	Normal
	true	Energy hold-off or dew-point mode
fanstageOverride	auto	Fan speed Automatic
	noChange (default)	Leave previous settigns (no change)
	speed0	Fan speed 0
	speed1	Fan speed 1
	speed2	Fan speed 2
	speed3	Fan speed 3
occupancy	frost	Room in frost mode
	occupied	Room occupied
	standby	Room in standby
	unoccupied	Room unoccupied
setpointShift	-10 ... 10 [°C], step 0.078	Linear set point shift