Direction "to": Actuator Set Output

Key	Value	Meaning
switch	off	Output value OFF
	on	Output value ON

Direction "from": Actuator Status Response

Key	Value	Meaning
localControl	off	Local control disabled / not supported
	on	Local control enabled
switch	off	Output value OFF
	on	Output value ON

Direction "to": Actuator Set Measurement

Key	Value	Meaning
resetMeasurement	false (default)	Reset measurement: not active
	true	Reset measurement: trigger signal

Direction "to": Actuator Query

Key	Value	Meaning
query	energy	Query energy
	status	Query status

Direction "from": Actuator Measurement Response

Key	Value	Meaning
energy	0 ... 4294967295000 [Wh], step 0.000278	Cumulative electricity value from meter