Direction "to": Actuator Set Output

Key	Value	Meaning
dimValue	0 ... 100 [%], step 1	Output value 0% to 100%
	invalid	Output value not valid / not applicable
rampingMode	rampingTime1 (default)	Dim to new output value using rampingTime1
	rampingTime2	Dim to new output value using rampingTime2
	rampingTime3	Dim to new output value using rampingTime3
	stop	Stop dimming
	switch	Switch to new output value

Direction "from": Actuator Status Response

Key	Value	Meaning
dimValue	0 ... 100 [%], step 1	Output value 0% to 100%
	invalid	Output value not valid / not applicable
localControl	off	Local control disabled / not supported
	on	Local control enabled

Direction "to": Actuator Set Measurement

Key	Value	Meaning
resetMeasurement	false (default)	Reset measurement: not active
	true	Reset measurement: trigger signal

Direction "to": Actuator Query

Key	Value	Meaning
query	energy	Query energy
	status	Query status

Direction "from": Actuator Measurement Response

Key	Value	Meaning
energy	0 ... 4294967295000 [Wh], step 0.000278	Cumulative electricity value from meter