Direction "to": Actuator Set Output

Key	Value	Meaning
dimValue	0 ... 100 [%], step 1	Output value 0% to 100%
	invalid	Output value not valid / not applicable
rampingMode	rampingTime1 (default)	Dim to new output value using rampingTime1
	rampingTime2	Dim to new output value using rampingTime2
	rampingTime3	Dim to new output value using rampingTime3
	stop	Stop dimming
	switch	Switch to new output value

Direction "to": Configure Actuator

Key	Value	Meaning
defaultState	off	Default state: 0% or OFF
	on	Default state: 100% or ON
	previousState (default)	Default state: remember previous state
overcurrentSwitchOffReset	false (default)	Reset over current shut down: not active
	true	Reset over current shut down: trigger signal
rampingTime1	0.5 ... 7.5 [s], step 0.5 (default 1)	Dim timer 1
rampingTime2	0.5 ... 7.5 [s], step 0.5 (default 4)	Dim timer 2
rampingTime3	0.5 ... 7.5 [s], step 0.5 (default 7.5)	Dim timer 3
taughtInDevices	off	Disable taught-in devices (with different EEP)
	on (default)	Enable taught-in devices (with different EEP)

Direction "from": Actuator Status Response

Key	Value	Meaning
dimValue	0 ... 100 [%], step 1	Output value 0% to 100%
	invalid	Output value not valid / not applicable
errorCode	failure	Error level 2: hardware failure
	noError	Error level 0: hardware OK
	notSupported	Error level not supported
	warning	Error level 1: hardware warning
localControl	off	Local control disabled / not supported
	on	Local control enabled
overcurrentSwitchOff	false	Over current switch off: ready / not supported
	true	Over current switch off: executed

Direction "to": Set Energy Measurement

Key	Value	Meaning
energyDelta	0 ... 4095000 [Wh], step 0.000278	Delta of energy to be reported
maxTimeBetweenReports	10 ... 2550 [s], step 10 (default 60)	Measurement Response messages
minTimeBetweenReports	0 ... 255 [s], step 1 (default 10)	Measurement Response messages
reportMeasurement	queryAndAuto (default)	Report measurement: query / auto reporting
	queryOnly	Report measurement: query only
resetMeasurement	false (default)	Reset measurement: not active
	true	Reset measurement: trigger signal

Direction "to": Set Power Measurement

Key	Value	Meaning
maxTimeBetweenReports	10 ... 2550 [s], step 10 (default 60)	Measurement Response messages
minTimeBetweenReports	0 ... 255 [s], step 1 (default 10)	Measurement Response messages
powerDelta	0 ... 4095000 [W], step 1	Delta of power to be reported
reportMeasurement	queryAndAuto (default)	Report measurement: query / auto reporting
	queryOnly	Report measurement: query only
resetMeasurement	false (default)	Reset measurement: not active
	true	Reset measurement: trigger signal

Direction "to": Actuator Query

Key	Value	Meaning
query	energy	Query energy
	power	Query power
	status	Query status

Direction "from": Actuator Measurement Response

Key	Value	Meaning
energy	0 ... 4294967295000 [Wh], step 0.000278	Cumulative electricity value from meter
power	0 ... 4294967295000 [W], step 1	Current power value from meter