Direction "to": Actuator Set Output

Key	Value	Meaning
switch	off	Output value OFF
	on	Output value ON

Direction "to": Configure Actuator

Key	Value	Meaning
defaultState	off	Default state: OFF
	on	Default state: ON
	previousState (default)	Default state: remember previous state
localControl	off	Disable local control
	on (default)	Enable local control
overcurrentSwitchOffMode	restart	automatic restart
	staticOff (default)	static off
overcurrentSwitchOffReset	false (default)	Reset over current shut down: not active
	true	Reset over current shut down: trigger signal
taughtInDevices	off	Disable taught-in devices (with different EEP)
	on (default)	Enable taught-in devices (with different EEP)
userInterfaceIndication	day (default)	User interface indication: day operation
	night	User interface indication: night operation

Direction "from": Actuator Status Response

Key	Value	Meaning
errorCode	failure	Error level 2: hardware failure
	noError	Error level 0: hardware OK
	notSupported	Error level not supported
	warning	Error level 1: hardware warning
localControl	off	Local control disabled / not supported
	on	Local control enabled
overcurrentSwitchOff	false	Over current switch off: ready / not supported
	true	Over current switch off: executed
switch	off	Output value OFF
	on	Output value ON