Direction "to": Actuator Set Output

Key	Value	Meaning
switch	off	Output value OFF
	on	Output value ON

Direction "to": Configure Actuator

Key	Value	Meaning
defaultState	off	Default state: OFF
	on	Default state: ON
	previousState (default)	Default state: remember previous state
localControl	off	Disable local control
	on (default)	Enable local control
taughtInDevices	off	Disable taught-in devices (with different EEP)
	on (default)	Enable taught-in devices (with different EEP)
userInterfaceIndication	day (default)	User interface indication: day operation
	night	User interface indication: night operation

Direction "from": Actuator Status Response

Key	Value	Meaning
localControl	off	Local control disabled / not supported
	on	Local control enabled
switch	off	Output value OFF
	on	Output value ON

Direction "to": Actuator Set External Interface Settings

Key	Value	Meaning
autoOffTimer	0.1 ... 6553.4 [s], step 0.1	Timer ON
	off	Timer OFF
delayOffTimer	0.1 ... 6553.4 [s], step 0.1	Delay Timer ON
	off	Delay Timer OFF
extButton	autoDetect	Auto detect
	extPushButton	External Push Button
	extSwitch	External Switch
	notApplicable	Not applicable
switchingState	preset	Specific ON/OFF positions. ON when contacs are closed. OFF when contacs are open
	toggle	Change of key state sets ON or OFF

Direction "to": Actuator Query

Key	Value	Meaning
query	extInterface	Query Status
	status	Query external interface settings

Direction "from": Actuator External Interface Repsonse

Key	Value	Meaning
autoOffTimer	0.1 ... 6553.4 [s], step 0.1	Timer ON
	off	Timer OFF
delayOffTimer	0.1 ... 6553.4 [s], step 0.1	Delay Timer ON
	off	Delay Timer OFF
extButton	autoDetect	Auto detect
	extPushButton	External Push Button
	extSwitch	External Switch
	notApplicable	Not applicable
switchingState	preset	Specific ON/OFF positions. ON when contacs are closed. OFF when contacs are open
	toggle	Change of key state sets ON or OFF