Direction "to": Actuator Set Output

Key	Value	Meaning
channel	0 ... 1, step 1	Output channel (to load)
	all	All output channels supported by the device
	input	Input channel (from mains supply)
switch	off	Output value OFF
	on	Output value ON

Direction "from": Actuator Status Response

Key	Value	Meaning
channel	0 ... 1, step 1	Output channel (to load)
	input	Input channel (from mains supply)
switch	off	Output value OFF
	on	Output value ON

Direction "to": Actuator Set Measurement

Key	Value	Meaning
channel	0 ... 1, step 1	Output channel (to load)
	all	All output channels supported by the device
	input	Input channel (from mains supply)
resetMeasurement	false (default)	Reset measurement: not active
	true	Reset measurement: trigger signal

Direction "to": Actuator Query

Key	Value	Meaning
channel	0 ... 1, step 1	Output channel (to load)
	all	All output channels supported by the device
	input	Input channel (from mains supply)
query	energy	Query energy
	status	Query status

Direction "from": Actuator Measurement Response

Key	Value	Meaning
channel	0 ... 1, step 1	Output channel (to load)
	input	Input channel (from mains supply)
energy	0 ... 4294967295000 [Wh], step 0.000278	Cumulative electricity value from meter