Direction "to": Actuator Set Output

Key	Value	Meaning
channel	0 ... 1, step 1	Output channel (to load)
	all	All output channels supported by the device
	input	Input channel (from mains supply)
switch	off	Output value OFF
	on	Output value ON

Direction "from": Actuator Status Response

Key	Value	Meaning
channel	0 ... 1, step 1	Output channel (to load)
	input	Input channel (from mains supply)
switch	off	Output value OFF
	on	Output value ON

Direction "to": Actuator Set External Interface Settings

Key	Value	Meaning
autoOffTimer	0 ... 6553 [s], step 0.1	Timer ON
	0	Timer OFF
delayOffTimer	0 ... 6553 [s], step 0.1	Delay Timer ON
	0	Delay Timer OFF
extButton	autoDetect	Auto detect
	extPushButton	External Push Button
	extSwitch	External Switch
	notApplicable	Not applicable
switchingState	0	Change of key state sets ON or OFF
	1	Specific ON/OFF positions. ON when contacs are closed. OFF when contacs are open

Direction "to": Actuator External Interface Query

Key	Value	Meaning
channel	0 ... 1, step 1	Output channel (to load)
	all	All output channels supported by the device
	input	Input channel (from mains supply)

Direction "from": Actuator External Interface Repsonse

Key	Value	Meaning
autoOffTimer	0 ... 6553 [s], step 0.1	Timer ON
	0	Timer OFF
delayOffTimer	0 ... 6553 [s], step 0.1	Delay Timer ON
	0	Delay Timer OFF
extButton	autoDetect	Auto detect
	extPushButton	External Push Button
	extSwitch	External Switch
	notApplicable	Not applicable
switchingState	0	Change of key state sets ON or OFF
	1	Specific ON/OFF positions. ON when contacs are closed. OFF when contacs are open