Direction "to": Go to Position and Angle

Key	Value	Meaning
angle	0 ... 100 [%], step 1	Rotation angle
	noChange (default)	Do not change
lockingMode	block	Set blockage mode
	noChange (default)	Do not change
	unblock	Deblockage
position	0 ... 100 [%], step 1	Vertical position
	noChange (default)	Do not change
repositioning	direct (default)	Go directly to POS/ANG
	firstDown	Go down (100%), then to POS/ANG
	firstUp	Go up (0%), then to POS/ANG

Direction "to": Stop

Key	Value	Meaning
stop	true	Stop command

Direction "to": Query Position and Angle

Key	Value	Meaning
query	status	Query command

Direction "from": Reply Position and Angle

Key	Value	Meaning
angle	0 ... 100 [%], step 1	Current rotation angle
	unknown	Angle currently unknown
lockingMode	block	Blockage mode
	unblock	Normal (no lock)
position	0 ... 100 [%], step 1	Current vertical position
	unknown	Position currently unknown