Ip representation:D2-05-03

IP KEY	Valid range	Step size	Unit	IP Meaning
position	0...100	1	%	Vertical position of blind/shutter or electrochrome glass zones
	127			noChange
Angle	0...100	1	%	blade orientation or electrochrom glass tint level
	127			noChange
Repositioning	0			direct
	1			firstUp
	2			firstDown
lockingMode	0			noChange
	1			block
	2			alarm
	7			unblock
channel	0			Channel 1
commandId	1			Goto command
Motorized sash	0...100	1	%	Opening of the motorized window (0%=close, 100% fully open)
Transmissivity	0...100	1	%	quantity of (sun) light that can go through the glass
Locking sensor 1	0			window open
	1			window closed
	2			sensor not available
	3			reserved
Locking sensor 2	0			window open
	1			window closed
	2			sensor not available
	3			reserved
Intrusion detected	0			intrusion detector not triggered
	1			intrusion detector triggered
	2			intrusion detector not available
	3			reserved

IP KEY	Valid range	Step size	Unit	IP Meaning
Solar protection	0			Solar protection without orientation available
	1			Solar protection with orientation available
	2			Solar protection with electrochromic glass available
	3			No solar protection available
Indoor Temperature	0...100	0.50	°C	Indoor Temperature
	101...255			reserved
Outdoor Temperature	0...200	0.50	°C	Outdoor Temperature
	201...255			reserved
Opening mode	0			Automode
	1			Manual override
Error state	0			No error
	1			Current Kill Error. This indicates the maximum current was exceeded. Typically there is a short in the wires somewhere. When this error occurs, all IGUs electrochromic glasses) connected to the controller will be turned off and cannot be tinted.
	2			IGU Not Tinting. The controller detects if there voltage and no current. Most likely issue is an open wire somewhere.
	3			IGU Warning. The controller detects that the IGU is not operating as expected. Most likely the IGU is still tinting, but may have some visual inconsistencies.
	4			Parameter Error. The controller detects an IGU parameter is out of bounds.In this case, all IGUs on that controller are turned off.This should only happen during commissioning, but is required to ensure our glass is controlled safely.
	5			System Error. Other potential system errors.This will most likely required replacement of the controller card or software update.

IP KEY	Valid range	Step size	Unit	IP Meaning
	6			Opening motorized error. the motor meets an issue for opening the sash; check if there isn't an obstacle; it could be necessary to call a technician
	7			Closing motorized error. the motor meets an issue for closing the sash; check if there isn't an obstacle; it could be necessary to call a technician
	8...15			reserved